



Using Avaya J129 SIP IP Phone in Avaya Aura®

Release 4.1.x
Issue 2
April 2026

Notices

© 2026 Avaya LLC. All Rights Reserved.

You may, at your own risk, assemble a MyDocs collection solely for your own internal business purposes, which constitutes a modification to the original published version of the publications. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of publications. You agree to defend, indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, your modifications, additions or deletions to the publications.

A single topic or a collection of topics may come from multiple Avaya publications. All of the content in your collection is subject to the legal notices and disclaimers in the publications from which you assembled the collection. For information on licenses and license types, trademarks, and regulatory statements, see the original publications from which you copied the topics in your collection.

Except where expressly stated by Avaya otherwise, no use should be made of materials provided by Avaya on this site. All content on this site and the publications provided by Avaya including the selection, arrangement and design of the content is owned by Avaya and/or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. Avaya owns all right, title and interest to any modifications, additions or deletions to the content in the Avaya publications.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published in varying media which may include product information, subscription or service descriptions, operating instructions and performance specifications that are generally made available to users of products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless such modifications, additions, or deletions were performed by or on the express behalf of Avaya. End user agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End user.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or Documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on Avaya hardware and software. Please refer to your agreement with Avaya to establish the terms of the limited warranty. In addition, Avaya's standard warranty language as well as information regarding support for this product while under warranty is available to Avaya customers and other parties through the Avaya Support website: <https://support.avaya.com/helpcenter/getGenericDetails?detailId=C20091120112456651010> under the link "Warranty & Product Lifecycle" or such successor site as designated by Avaya. Please note that if the product(s) was purchased from an authorized Avaya channel partner outside of the United States and Canada, the warranty is provided by said Avaya Channel Partner and not by Avaya.

"Hosted Service" means an Avaya hosted service subscription that You acquire from either Avaya or an authorized Avaya Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Avaya or Avaya Channel Partner (as applicable) for more information.

Hosted Service

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN AVAYA HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE). THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA WEBSITE, [HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO](https://support.avaya.com/licenseinfo) UNDER THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE

TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE.

Licenses

The Global Software License Terms ("Software License Terms") are available on the following website <https://www.avaya.com/en/legal-license-terms/> or any successor site as designated by Avaya. These Software License Terms are applicable to anyone who installs, downloads, and/or uses Software and/or Documentation. By installing, downloading or using the Software, or authorizing others to do so, the end user agrees that the Software License Terms create a binding contract between them and Avaya. In case the end user is accepting these Software License Terms on behalf of a company or other legal entity, the end user represents that it has the authority to bind such entity to these Software License Terms.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Avaya. All content on this site, the documentation, Hosted Service, and the product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Unless otherwise stated, each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two Instances of the same type of products, then two products of that type must be ordered.

Third Party Components

The following applies only if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).

Service Provider

WITH RESPECT TO CODECS, IF THE AVAYA CHANNEL PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED THE H.264 CODEC OR H.265 CODEC, THE AVAYA CHANNEL PARTNER ACKNOWLEDGES AND AGREES THE AVAYA CHANNEL PARTNER IS RESPONSIBLE FOR ANY AND ALL RELATED FEES AND/OR ROYALTIES. THE H.264 (AVC) CODEC IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO: (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).

Compliance with Laws

You acknowledge and agree that it is Your responsibility to comply with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Avaya product is used.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If You suspect that You are being victimized by Toll Fraud and You need technical assistance or support, please contact your Avaya Sales Representative.

Security Vulnerabilities

Information about Avaya's security support policies can be found in the Security Policies and Support section of <https://support.avaya.com/security>.

Suspected Avaya product security vulnerabilities are handled per the Avaya Product Security Support Flow (<https://support.avaya.com/css/P8/documents/100161515>).

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: <https://support.avaya.com>, or such successor site as designated by Avaya.

Contact Avaya Support

See the Avaya Support website: <https://support.avaya.com> for Product or Cloud Service notices and articles, or to report a problem with your Avaya Product or Cloud Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <https://support.avaya.com> (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

Note

Using a cell, mobile, or GSM phone, or a two-way radio in close proximity to an Avaya IP telephone might cause interference.

Regulatory Statements

Australia Statements

Handset Magnets Statement:

Danger:

The handset receiver contains magnetic devices that can attract small metallic objects. Care should be taken to avoid personal injury.

Industry Canada (IC) Statements

RSS Standards Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage, et
4. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radio Transmitter Statement

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Radiation Exposure Statement

This equipment complies with FCC & IC RSS102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

Japan Statements

Class B Statement

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。 VCCI-B

Denan Power Cord Statement

Danger:

Please be careful of the following while installing the equipment:

- Please only use the connecting cables, power cord, and AC adapters shipped with the equipment or specified by Avaya to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning, or fire.
- Power cords shipped with this equipment must not be used with any other equipment. In case the above guidelines are not followed, it may lead to death or severe injury.



警告

本製品を安全にご使用頂くため、以下のことにご注意ください。

- 接続ケーブル、電源コード、ACアダプタなどの部品は、必ず製品に同梱されており添付品または指定品をご使用ください。添付品指定品以外の部品をご使用になると故障や動作不良、火災の原因となることがあります。
- 同梱されており添付の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

México Statement

The operation of this equipment is subject to the following two conditions:

1. It is possible that this equipment or device may not cause harmful interference, and
2. This equipment or device must accept any interference, including interference that may cause undesired operation.

La operación de este equipo está sujeta a las siguientes dos condiciones:

1. Es posible que este equipo o dispositivo no cause interferencia perjudicial y
2. Este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Brazil Statement

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados

Power over Ethernet (PoE) Statement

This equipment must be connected to PoE networks without routing to the outside plant.

Taiwan Low Power Radio Waves Radiated Devices Statement

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

U.S. Federal Communications Commission (FCC) Statements

Compliance Statement

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interferences that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designated to provide reasonable protection against harmful interferences in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferences to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 8 in or 20 cm between the

radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ENERGY STAR® compliance statement



As an ENERGY STAR partner, Avaya LLC has determined that this product meets the ENERGY STAR guidelines for energy efficiency. Information on the ENERGY STAR program can be found at www.energystar.gov. ENERGY STAR and the ENERGY STAR mark are registered trademarks owned by the U.S. Environmental Protection Agency.

EU Countries

This device when installed complies with the essential requirements and other relevant provisions of the EMC Directive 2014/30/EU, Safety LV Directive 2014/35/EU, and Radio Equipment Directive 2014/53/EU. A copy of the Declaration may be obtained from <https://support.avaya.com> or Avaya LLC, 350 Mt. Kemble Avenue, Morristown, NJ 07960 USA.

WiFi transmitter

- Frequencies for 2412-2472 MHz, transmit power: < 20 dBm
- Frequencies for 5180-5240 MHz, transmit power: < 20 dBm

General Safety Warning

- Use only the Avaya approved Limited Power Source power supplies specified for this product.
- Ensure that you:
 - Do not operate the device near water.
 - Do not use the device during a lightning storm.
 - Do not report a gas leak while in the vicinity of the leak.
 - For Accessory Power Supply in Avaya J100 Series IP Phones— Use Only Limited Power Supply Phihong Technology Co. Ltd. Model: PSAC12R-050, Output: 5VDC, 2.4A.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, its licensors, its suppliers, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya LLC.

All non-Avaya trademarks are the property of their respective owners.

Device Usage Consent

By using the Avaya device, you agree that Avaya, from time to time, may collect network and device data from your device and may use such data in order to validate your eligibility to use the device.

Contents

Chapter 1: Introduction	8
Purpose.....	8
Chapter 2: Avaya J129 IP Phone overview	9
Physical layout of a J129 IP Phone.....	10
Connection jacks for Avaya J129 IP Phone.....	11
Supported features.....	13
Chapter 3: Getting started	15
Entering the provisioning server details.....	15
Identifying the device type during phone boot-up.....	16
Logging in to your phone.....	16
Logging out of your phone.....	17
Locking your phone.....	17
Unlocking your phone	18
Setting the network mode.....	18
Setting the network configuration.....	19
Connecting to a Wi-Fi network.....	20
Chapter 4: Navigation	22
Main Menu.....	22
Icons on the phone.....	22
Chapter 5: Incoming calls	25
Answering a call.....	26
Answering a call when on another call.....	26
Viewing a missed call.....	27
Ignoring a call.....	27
Transferring a call on hold.....	28
Chapter 6: Outgoing calls	29
Making a call by using the dial mode.....	29
Making a call without using the dial mode.....	29
Redialing a number.....	29
Making a call using speed dial.....	30
Toggling between calls.....	30
Making a call from the local contacts list.....	30
Making a call from the corporate database Contacts list.....	31
Making a call from Recents.....	31
Emergency call.....	32
Making an emergency call.....	32
Making an international call.....	33
Chapter 7: Managing contacts	34
Adding a new contact.....	34

Editing a contact.....	35
Viewing local contact details.....	35
Searching for a contact.....	35
Deleting a contact.....	36
Chapter 8: Call history.....	37
Call log.....	37
Turning call history on and off.....	38
Viewing the Recents details.....	38
Managing a call record in the Recents list.....	39
Clearing the Recents list.....	39
Chapter 9: Conference calls.....	40
Adding a person to an active call.....	40
Adding a person on hold to a conference call.....	40
Putting a conference call on hold and resuming a call.....	41
No Hold Conference.....	41
Adding a participant to no hold conference.....	41
Chapter 10: Call related features.....	43
Muting and unmuting a call.....	43
Placing a call on hold and resuming the call.....	43
Resuming a held call by using Hold button.....	44
Off-hook alert.....	44
Chapter 11: Do not disturb and Call Forward.....	45
Do not disturb.....	45
Activating and deactivating Do not disturb.....	45
Call forwarding.....	46
Forwarding a call to another extension.....	46
Activating EC500.....	47
Chapter 12: Advanced features.....	48
Accessing the Features screen.....	48
Activating transfer to voice mail.....	48
Blocking your extension from displaying during calls.....	49
Intercom.....	49
Multiple Device Access.....	49
Handling calls and conferences using Multiple Device Access.....	50
Multicast Paging.....	50
Sending a multicast page.....	51
Parking and unparking a call.....	51
Making an attended transfer.....	52
Making an unattended transfer.....	52
Setting up automatic call back.....	53
Shared control.....	53
Tracing a malicious call.....	54
Voicemail.....	54

Listening to your voicemail.....	55
Chapter 13: Phone customization.....	56
Phone.....	56
Setting the Dial mode.....	56
Displaying call timers.....	56
Assigning Speed Dial.....	57
Replacing and clearing a Speed Dial contact.....	57
Activating Mute Alert.....	57
Visual alerting.....	58
Audio.....	59
Setting a ring tone for incoming calls.....	59
Turning button clicks on and off.....	59
Turning error tones on and off.....	59
Turning audio settings on and off.....	60
Setting Handset Profile.....	60
Sidetone of your handset.....	60
Display.....	61
Adjusting the contrast of the display screen.....	61
Setting the display language.....	61
Setting the date format.....	61
Setting the time format.....	62
Setting the time zone.....	62
Backup and restore.....	63
Backup and restore overview.....	63
Chapter 14: Phone update.....	64
Updating your phone.....	64
Checking your phone periodic automatic update.....	64
Chapter 15: Maintenance.....	66
Viewing the product ID.....	66
Viewing the device type.....	66
Viewing the secondary provisioning server address.....	67
Viewing the server type.....	67
Chapter 16: Resources.....	68
Documentation.....	68
Finding documents on the Avaya Support website.....	70
Avaya Documentation Center navigation.....	71
Viewing Avaya Mentor videos.....	72
Support.....	73

Chapter 1: Introduction

Purpose

This document describes the features of the Avaya J129 IP Phone and also provides instructions on how to use this phone.

This document is for end users.

Chapter 2: Avaya J129 IP Phone overview

The Avaya J129 IP Phone is a SIP-based phone intended to be used for basic business communications. The phone supports two-call appearances with a single-line call display.

Physical specifications

- Single call appearance
- A 128 x 32 pixels graphical LCD
- Three softkeys
- Dual 10/100 network ports
- Power over Ethernet class one device
- Magnetic Hook Switch

Physical layout of a J129 IP Phone



Callout number	Name	Description
1	Beacon LED	Displays a flashing red light to indicate a voice mail or incoming calls. The Beacon LED also flashes when you are on a call using the hands free speaker capability.
2	Phone display	Displays information such as time, softkey labels, and menu items. If a text is wider than the display area, then the text is followed by three dots. Use the Right and Left Arrow keys to scroll through the text. If there is a scroll bar or a line indicator at the right of the phone display, use the up and down arrow keys to scroll up and down.
3	Soft keys	Displays screen-specific commands.
4	OK	Selects the function assigned to the left soft key.
5	Navigation arrows	Navigates between various menu options. <ul style="list-style-type: none"> • Up and Down arrow keys: To scroll up and down. • Right and Left arrow keys: To move cursor in the text input field, and to toggle values in the selection fields.
6	Phone	Displays the Phone screen.
7	Back	Cancels the current action and returns to the previous menu.
8	Speaker	Activates and deactivates the speakerphone. You can also lift the handset to deactivate the speakerphone.
9	Main menu	Displays the menu options and other phone settings.
10	Hold	Puts the call on hold.
11	Volume	Increase or decreases the volume of the handset, or speaker when you are on a call. Adjusts the ringer volume when you are not on a call.
12	Mute	Mutes and unmutes the microphone.
13	Mic	The mic of the phone. It is positioned on the front panel for J129D03A and later models.

Connection jacks for Avaya J129 IP Phone

The following image illustrates the connection jacks that are present on the back panel of Avaya J129 IP Phone. The image schematically describes which device to connect in which jack.



No.	Name	Description
1	5V DC Jack	To connect the power supply. * Note: Available only in J129D03A and later models.
2	Network port	To connect the Ethernet cable
3	PC port	To connect the computer. * Note: PC port is disabled when Wi-Fi network is used.
4	Handset Jack	To connect the handset.
5	WLAN Module Panel	To integrate the Wi-Fi module.

*** Note:**

Headset is not supported in Avaya J129 IP Phones.

Supported features

Features	Avaya Aura®	IP Office
End to end security indicator	Yes	No
Private Call	Yes	Yes. It is supported using short codes.
Call Forward	Yes	Yes. It is supported using short codes.
Emergency dialing when user not logged in	Yes	No
Conference calls	Yes	Yes. Conference call supports three participants and the call is hosted on the phone.
Attended Transfer	Yes	Yes
Unattended Transfer	Yes	Yes
Transferring a call by selecting a contact or Recents	Yes	Yes
Contacts	Yes	Yes. Personal contacts only.
Presence	Yes	No

Table continues...

Avaya J129 IP Phone overview

Quick log in	Yes	No
Multiple Device Access (MDA) ¹	Yes	No
Voice mail	Yes	Yes
Call Park/Unpark	Yes	Yes. It is supported using short codes.
Block Calling party info	Yes	No
EC500	Yes	No
Malicious Call Trace (MCT)	Yes	No
Do Not Disturb	Yes	Yes. It is supported using short codes.
Automatic Call Back	Yes	No
Dial mode	Yes	Yes. It supports only manual mode.
Speed Dial	Yes	No

For more information on IP Office, see IP Office documents in <https://support.avaya.com/>.

¹ The MDA feature is supported in Avaya J129 IP Phone with limitations. For more information, see “Multiple Device Access”.

Chapter 3: Getting started

Entering the provisioning server details

About this task

If the phone can not obtain the provisioning server URL from Device Enrollment Services, DHCP SSON, or LLDP, the phone prompts the user to manually enter the provisioning server details.

Before you begin

Ensure that you have the provisioning server address. Contact the system administrator for the provisioning server address.

Procedure

1. When you boot the phone for the first time, the Auto Provisioning screen displays `Do you want to activate Auto Provisioning now?`, press one of the following:
 - **Yes**: To connect to the Device Enrollment Services server to obtain the provisioning server address and ignore the provisioning server address from the DHCP.
 - **No**: To obtain the provisioning server address from the DHCP server.

In case of a time out, and the DHCP does not provide the provisioning server address, the phone selects **Yes**.

If the connection to Device Enrollment Services is successful, and the phone receives the provisioning server address, the phone continues to boot and not prompt you for the provisioning server address.

If the connection to Device Enrollment Services is successful, and the phone does not receive the provisioning server address from Device Enrollment Services, the phone prompts you for a Numeric Enrollment code. Contact your administrator for a numeric enrollment code. When you enter the valid numeric enrollment code, the phone continues to boot and not prompt you for the provisioning server address.

If you do not have a numeric enrollment code, press **Cancel**. The phone continues to boot using the DHCP.

The phone displays the `Starting` message. If the phone does not receive the provisioning server address from the Device Enrollment Services or the DHCP server, the phone displays the Enter provisioning details screen.

2. On the Enter provisioning details screen, press one of the following:
 - **Config**: To enter the provisioning server address.

- **Never:** To never prompt for the provisioning server address.
 - **Cancel:** To cancel the prompt and display the Login screen.
3. Press **Config**, and in the **Addr** field, enter the provisioning server address.

The address is an alphanumeric URL. For example, `http://myfileservr.com/j100/`.

 **Tip:**

To enter the dot symbol (.), press the alphanumeric soft key to toggle to the ABC mode.

To enter the forward-slash symbol (/), press the / soft key.

4. **(Optional)** Enter the **Group** number.

Obtain the Group number from your system administrator. The value ranges from 0 to 999. If you do not enter a value, the phone uses the default value of 0.

5. Press **Save**.

The phone continues the boot process and connects to the provisioning server.

Identifying the device type during phone boot-up

About this task

Avaya J100 Series IP Phones screen displays the device type during the phone boot-up. This feature is supported from the phone software version 4.0.3 and later.

Procedure

1. Set up the phone hardware.
2. Plug the Ethernet cable to the phone.

The phone powers up and starts to initialize.

The phone screen displays `Starting... Avaya SIP`.

Logging in to your phone

About this task

Perform this task to log in to your phone.

Before you begin

Get the log in password from the system administrator.

Procedure

1. Press **Login**.
2. Enter your extension.
3. Press **Enter** or **OK** or **#**.
4. Enter the password that the administrator assigned to you.
5. Press **Enter** or **OK** or **#**.

Logging out of your phone

About this task

If the administrator enables the offline call-log feature, missed calls are added to the call history. The offline call-log feature is only available in an Avaya Aura® environment.

Procedure

1. Press **Main menu** > **Log out**.

 **Note:**

In IP Office, press **Main menu** > **Admin** > **Log out**. For more information, see IP Office documents in <https://support.avaya.com/>.

2. Press **Log out** when the phone prompts for confirmation.

Locking your phone

About this task

Lock the phone while you are logged in to prevent unauthorized usage. Locking the phone does not log you out. You can receive all incoming calls and make calls to emergency numbers.

If the Single sign-on (SSO) feature is active on your phone, you cannot lock the phone before setting a PIN.

Before you begin

Contact your phone administrator if you cannot see the **Lock** option in the **Application** menu.

Procedure

1. Press **Main menu**.
2. Select **Lock**.

Unlocking your phone

About this task

Unlock the phone using a PIN or a password. Depending on the configuration, the phone displays the field for entering a PIN or a password.

When the Single sign-on (SSO) feature is active, you can unlock the phone only with the PIN you set. When SSO is inactive, you can unlock the phone with the PIN you set, an administrator-defined PIN or the SIP password.

If your phone administrator does not set a PIN when SSO is inactive, the phone displays the field to enter a password. If your phone administrator sets a PIN when SSO is inactive, or you set a PIN when SSO is active or inactive, the phone displays the field to enter a PIN. A PIN is a digit-only value and a password can be an alphanumeric value.

You cannot unlock the phone if you enter an incorrect PIN or password. The phone administrator sets the maximum number of incorrect attempts. If you exceed the limit, the phone temporarily blocks you from attempting to unlock the phone for a period that the administrator specifies.

If you do not know or remember your PIN or password when the SSO feature is inactive, contact your phone administrator. If you do not remember the PIN you set when the SSO feature is active, the phone prompts you to enter your administrator-defined password.

Procedure

1. Press **Unlock**.
2. On the phone screen, enter a PIN or a password.
The phone displays the `Invalid PIN` prompt if you enter an incorrect PIN.
3. **(Optional)** If you do not remember the PIN you set, do the following:

- a. Press **Forgot**.

The phone displays the `You need to re-login to setup new PIN` prompt.

- b. Press **Log Out**.
- c. Enter your administrator-defined username and password.

Setting the network mode

About this task

Perform this procedure to set the network mode of your phone to an **Ethernet** or a specific **Wi-Fi** network.

Before you begin

Ensure that the network administrator gives you access to perform this task.

Procedure

1. Press **Main Menu**.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Network** and press **Select**.
4. Scroll to **Network mode**.
5. Select the **Network mode** from the following options:
 - **Ethernet**: To connect the phone to an Ethernet network.
 - **Wi-Fi**: To connect the phone to a Wi-Fi network.
6. Press one of the following:
 - **Toggle**
 - **Right** arrow key
 - **Left** arrow key
7. Press **Save**.
8. When the phone prompts to restart, press **OK** or press **Cancel** to go back.

Related links

[Setting the network configuration](#) on page 19

[Connecting to a Wi-Fi network](#) on page 20

Setting the network configuration

About this task

Use this procedure to set the network configuration to Auto or Manual. You need to perform this procedure if your phone is not configured to connect to Ethernet or a specific Wi-Fi network.

When network configuration is Auto, every time the phone restarts, it connects to the pre-configured network your administrator has set up.

When network configuration is Manual, every time the phone restarts, it connects to the network that you manually configured by [Setting the network mode](#) on page 18 or [Connecting to a Wi-Fi network](#) on page 20, irrespective of the pre-configured network that your administrator has set up.

* Note:

When you change the connected network, the phone automatically sets the **Network config** to **Manual**.

Procedure

1. Press **Main Menu**.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Network** and press **Select**.

4. Scroll to **Network config**.

The Network configuration shows the following two options:

- **Auto**: To automatically connect to a network.
- **Manual**: To manually connect to a network.

5. Press one of the following:

- **Toggle**
- **Right** arrow key
- **Left** arrow key

6. Press one of the following:

- **Save**
- **OK**

 **Note:**

If your phone does not restart and stays in Manual mode even when you switch **Network config** from **Auto** to **Manual**, press **Save**.

If you switch **Network config** from **Manual** to **Auto**, press **Save** and then do either of the following:

- If the connected network is the same as the pre-configured network that your administrator has set up, the phone will not restart and stays in Auto mode.
- If the connected network is not the same as the pre-configured network that your administrator has set up, the phone prompts you for permission to restart before connecting to the pre-configured network.

Related links

[Setting the network mode](#) on page 18

Connecting to a Wi-Fi network

About this task

Perform this procedure to connect your phone to a specific Wi-Fi network.

Before you begin

- Ensure that the network administrator gives you the access to perform this task.
- Select Wi-Fi as your network mode.
- When you set the network mode, note the SSID, as this is the name of the Wi-Fi network the phone attempts to connect to.
- Ensure that the network administrator enables hidden Wi-Fi features.

Procedure

1. Press **Main Menu**.

2. Scroll to **Settings** and press **Select**.
3. Scroll to **Network** and press **Select**.
4. To access the list of available Wi-Fi networks, scroll to **Wi-Fi network** and press **Select**.
The phone displays all available Wi-Fi networks, including the hidden Wi-Fi networks.
5. Scroll to the required **Wi-Fi network** and press **Connect** to start the connection process.
You can connect to the hidden Wi-Fi network.
6. To restart the phone, press **OK**.
7. If the security is WEP or WPA/WPA2 PSK, in **Password**, enter the password for the Wi-Fi network.
Depending on the type of security in the Wi-Fi networks, obtain the required credentials.
Contact your network administrator for more details.
8. If the security is 802.1x EAP, enter the following:
 - **Identity**: Your user ID or the shared user ID provided by your administrator.
 - **Anonymous Identity**: Leave blank or use the shared Anonymous Identity provided by your administrator.
 - **Password**: Your password or the shared password provided by your administrator.

Result

When the authentication is successful, the phone automatically restarts to complete the connection.

Related links

[Setting the network mode](#) on page 18

Chapter 4: Navigation

Main Menu

The following table describes each of the Main menu options.

Name	Description
Recents	To view the call history.
Contacts	To add, edit, or delete a contact.
Voice Mail	To check your voice messages.
Features	To access administrator activated features
Settings	To change your phone settings, audio settings, display settings, and more.
Network Information	To check network settings.
Lock	To lock your phone.
Log Out	To sign off the phone, to protect your settings, or to let another user to log in.
Administration	To access administration settings.
About IP Deskphone	To display the phone software version, and the default device type.

Icons on the phone

The following table lists the icons used in the Avaya J129 IP Phone:




Icon	Description
	Line indicator; first call appearance
	Line indicator; second call appearance
	More than 10 recent missed calls

Table continues...































Icon	Description
	Recents- Outgoing call
	Recents- Missed call
	Recents- Incoming call
	Outgoing recents MDA
	Missed call
	Check
	MDA active
	New call setup
	Voicemail
	Checkbox off
	Checkbox on
	Active conference
	Conference on hold
	Contrast
	EC500
	Failover
	Radio button off
	Radio button on
	Feature unavailable
	Call forward
	Handset

Table continues...

Navigation

Icon	Description
	Hold
	Phone lock
	Ringer on
	Ringer off
	Speaker
	Do not disturb
	Mute
	Caller ID validation passed.
	Caller ID validation failed

Chapter 5: Incoming calls

An inbound call to your phone is an incoming call. For an incoming call, the phone provides audio and visual alerts. The phone screen displays the incoming call icon and the caller number or name. Depending on the configuration, the phone screen provides additional details on the incoming call such as the organization name and the department name. Scroll through the phone screen to view all the details. Your phone administrator configures the settings to display the caller ID details. Contact your administrator to enable caller ID details.

If your administrator has enabled the Block Incoming Calls feature, you cannot answer incoming calls when the phone is locked.

If you save an LDAP contact in the Local contacts of the phone from an LDAP directory, the phone displays that caller name from the Local contacts.

If you receive multiple calls simultaneously, the phone screen displays the second call details on the next page of the phone screen.

Caller ID validation

When you receive an incoming private or bridged call, the phone displays validation status information to prevent caller ID spoofing. You can view the caller ID validation status of an incoming call to verify whether you can trust the source of the call. If the incoming call popup feature is active on your phone, you can see the caller ID validation status on the popup. You can also see the status on the Call Details screen and CA/BCA lines. The validation statuses are the following:

- Passed: Successfully validated caller indication.
- Failed: Failed caller indication.

Your phone administrator configures the settings to display caller ID validation statuses.

Related links

[Answering a call](#) on page 26

[Answering a call when on another call](#) on page 26

[Viewing a missed call](#) on page 27

[Ignoring a call](#) on page 27

[Transferring a call on hold](#) on page 28

Answering a call

About this task

Use this procedure to answer a call. When you receive a call, the phone does the following:

- Generates audio-visual alerts.
- Displays the caller's name or number.

Procedure

Do one of the following:

- Lift the handset.
- Press **Speaker**.
- Press **OK** button.
- Press the **Answer** soft key.

Related links

[Incoming calls](#) on page 25

[Placing a call on hold and resuming the call](#) on page 43

Answering a call when on another call

About this task

You can receive a call on a secondary call appearance only if the call appearance is free.

Procedure

Press one of the following:

- The **Answer** soft key
- **OK Button**

The phone puts the first call on hold and moves to the second call.

Related links

[Incoming calls](#) on page 25

Viewing a missed call

About this task

If you missed answering a call, the phone screen displays the missed call icon. You can view the following details of a missed call on the Recents screen:

- Missed call icon
- Caller name, if the caller is added to contacts
- Missed call reason
- Extension number
- Missed call date and time

Note:

If the Voicemail feature is active, the phone redirects the unanswered call to your Voicemail number.

Procedure

1. On the Phone screen, press one of the following:
 - **Main menu > Recents**
 - **Recents**
2. Scroll to the required missed call.
3. Press **Details**.

You can view the details of the missed call.

Related links

[Incoming calls](#) on page 25

Ignoring a call

About this task

When you do not want to answer a call or you are on another call, you can ignore the new incoming call. When you ignore a call, only the ring alert on your phone stops, you can still answer this call within its ring time by using the Navigation cluster to select the call and answer it.

Procedure

On the Incoming call screen, press one of the following:

- The **Ignore** soft key
- **Back**

The phone turns off the audio alert and returns to the previous screen.

Related links

[Incoming calls](#) on page 25

Transferring a call on hold

About this task

Use this procedure to transfer a call on hold to an outgoing or an incoming call.

Before you begin

Press **Hold** to put an ongoing call on hold.

Procedure

1. Press one of the following soft keys:
 - **NewCall**: To make a new call.
 - **Resume**: To resume the call
2. When the called party answers the call or you answer the call, press the **Transfer** soft key.
3. Press the **Transfer** soft key again when the phone prompts for confirmation.

Related links

[Incoming calls](#) on page 25

Chapter 6: Outgoing calls

Making a call by using the dial mode

About this task

Use this procedure to make a call without lifting the handset or pressing **Speaker**.

Before you begin

Set the dial mode on the phone to **Auto** or **Manual**.

- If the dial mode is set to **Auto**, dial the required number of digits.
The phone initiates the call when the inter digit timer times out.
- If the dial mode is set to **Manual**, dial the number and press the **Call** softkey or **OK** button.

Related links

[Setting the Dial mode](#) on page 56

Making a call without using the dial mode

Procedure

1. Lift the handset or press **Speaker**.
2. Press the digits on the dial pad.

The phone initiates the call when the inter digit timer times out.

Redialing a number

About this task

Use this procedure to redial a number. If you delete the outgoing call log, the last dialed number is deleted.

Procedure

On the Phone screen, press one of the following:

- **Redial**
- If **Redial** softkey is the first softkey, press **OK**.

Making a call using speed dial

Before you begin

Ensure that you have assigned speed dial numbers to your contacts.

Procedure

Press and briefly hold the dial pad key assigned to the person you want to call.

Related links

[Assigning Speed Dial](#) on page 57

Toggling between calls

About this task

Use this procedure to toggle between calls when you are attending a call while a call is on hold.

Procedure

1. Press **Toggle**.
The current call goes on hold and the other resumes.
2. Press **Toggle** again to go back to the first call.

Making a call from the local contacts list

About this task

Use this procedure to make a call from the local contacts list. In an Open SIP environment, the local contacts are synchronized with the network file server.

Procedure

1. Press **Main Menu > Contacts**.
The phone displays the message `Use dial pad to search`.

2. Press the digits on the dial pad that correspond to the letters of the name of the person you want to call.

For example, press 764 to search for someone whose name is Smith.

3. Press one of the following to start a call to the selected number:

- **Call**
- **OK**

Making a call from the corporate database Contacts list

About this task

Depending on the configuration by your administrator you may be able to search and call contacts from other remote contacts lists or directories.

Procedure

1. On the Phone screen, press one of the following:
 - **Main menu > Contacts > Search.**
 - **Contacts > Search.**
2. Press **Search**.
3. Enter the digits on the dial pad that correspond to the name of the person you want to call.
For example, press 76484 to search for someone whose name is Smith.
4. Press **Search** again.
The phone displays the contact saved in the corporate database.
5. Press **Call**.

Making a call from Recents

About this task

Use this procedure to make a call from call history. If the system administrator configures emergency calling for your phone, the **Emerg** softkey replaces the **Recents** soft key.

Procedure

1. On the Phone screen, press one of the following:
 - **Main menu > Recents**
2. Use the **Up** and **Down Arrow** keys to select the contact that you want to call.

3. **(Optional)** Press **Details**.
4. Press **Call**.

Emergency call

Emergency calling is used to connect to a preset emergency services number. The emergency service number is configured by the administrator.

You can make an emergency call from the following screens:

- Login screen
- Phone screen
- Lock screen

In the IP Office environment, you can make an emergency call only when you are logged in to your phone.

If your system administrator configures emergency calling for your phone, the Phone screen displays the **Emerg** soft key.

Otherwise, the **Recents** soft key replaces the **Emerg** soft key.

Using the **Emerg** soft key, you can dial only the number that is given the highest priority by the system administrator. Alternatively, you can dial the emergency numbers by using the dial pad in the following cases:

- The **Emerg** soft key is unavailable.
- The **Emerg** soft key is available, but you want to dial an emergency number that is not set by the system administrator.

In the IP Office environment, the **Emerg** soft key is unavailable. You must dial the emergency number by using the dial pad.

For more information on IP Office, see IP Office documents in <https://support.avaya.com/>.

Making an emergency call

Before you begin

Ensure that the **Emerg** soft key is assigned by your administrator.

Procedure

Do one of the following:

- On the Phone screen, press the **Emerg** soft key, and again press **Emerg** when the phone prompts you for confirmation.
- Dial the emergency number by using the dial pad.

Making an international call

Procedure

1. Press and hold the **0** key to enter the plus sign (+).
2. Dial the number that you want to call.

Chapter 7: Managing contacts

Adding a new contact

About this task

Use this procedure to add a contact to the phone. You can save up to 250 contacts.

Procedure

1. To open Contacts list, do one of the following:
 - Press **Contacts**.
 - Press **Main menu**, and select **Contacts**.
2. Do one of the following:
 - If your Contacts list is empty, press **New**.
 - If your Contacts list is not empty, press **More > Contacts**.
3. Use the dial pad to enter the contact's first and last name in the corresponding fields.
 - Press the number key that corresponds to the letter or number that you want to enter.
 - If the characters are on the same key, pause before entering the next character.
 - To enter a space, press **0**.
 - Enter the remaining letters or numbers.
 - To enter a symbol, press **More > Symbol**. Use the navigation arrows to highlight the symbol that you want to enter and press **Insert**.
 - To delete the last character, press the **Bksp** soft key.
4. Enter the extension.

The contact extension can include uppercase and lowercase letters, numbers 0 - 9, and special symbols, such as comma (,), plus (+), and dot (.).
5. Press **Save**.

Editing a contact

About this task

Edit a contact in the Contacts list.

Procedure

1. Do one of the following:
 - Press **Contacts**.
 - Press **Main menu > Contacts**.
2. Select the contact.
3. Press **More**.
4. Press **Details > Edit**.
5. Scroll to the field to edit.
6. Use the dial pad and soft keys to change the contact information.
7. Press **Save**.

Viewing local contact details

Procedure

1. Do one of the following:
 - Press **Contacts**.
 - Press **Main menu > Contacts**.
2. Press **More**.
3. Press **Details**.
 - To call a contact, press **Call**.
 - To edit a contact, press **Edit**.
 - To delete a contact, press **Delete**.
 - To view more options, press **More**.

Searching for a contact

About this task

Use this procedure to search contacts from the local contacts list or enterprise directory. However, in IP Office environment, you can search for a contact only from the local contacts list.

For more information on IP Office , see IP Office documents in <https://support.avaya.com/>.

Procedure

1. To search for a contact from the local contacts, do the following:
 - a. Press **Main menu > Contacts**.
The phone displays the message `Use dial pad to search`.
 - b. Press the digits on the dial pad that correspond to the letters of the name of the person you want to call. For example, press 764 to search for someone whose name is Smith.
2. To search for a contact from the enterprise directory, do the following:
 - a. On the Phone screen, press **Contacts > Search** or press **Main menu > Contacts > Search**.
 - b. Use the dial pad to enter the name.
 - c. Press **Search**.
To add the contact to the local contacts, press **+Contact**.

Deleting a contact

About this task

You can delete your local contacts.

Procedure

1. Do one of the following:
 - Press **Contacts**.
 - Press **Main menu > Contacts**.
2. Select the contact to delete.
3. Press **More > Details > Delete**.
4. Press one of the following:
 - **Delete**: To delete the contact.
 - **Cancel**: To cancel the action.

Chapter 8: Call history

Call log

A call log provides a list of the last 100 calls on the phone. The call log list is sorted by the timestamps, with the latest call at the top of the list. Each entry in the call log has the following information:

- Call type icon
- Caller name
- Caller number
- Call time-stamp
- Call duration

You must enable the call log option for your extension to record the call entries. If you enable the summarize call logs option, you can view the aggregate of calls for each day. The phone sums up the calls for each call type from a caller and lists them in the Recents screen.

If you do not want the phone to log the **Call forward** or **Call forward-Busy** as a missed call, contact your administrator to make the required settings. If the primary extension user has logged out of the phone, the phone logs the forwarded-all call or forwarded-busy call as a missed call.

Missed call reason

For missed calls, the phone additionally displays the reason for the missed call that the call server provides. If you have an Offline call log enabled on your phone, the phone loses the call forwarding status in the missed call reason. Avaya J100 Series IP Phones display the following reasons for missing the call if any of the following features are active on your phone:

Feature	Missed call reason
Call forward	All calls forwarded
Call forward Busy	Busy on other calls
All Lines Busy	All call appearances busy
Limit Number of Concurrent Calls (LNCC)	Limit incoming calls
Coverage	No answer

Avaya J100 Series IP Phones encrypt the content of the call log file from the software version 4.0.3 and later.

If you need to downgrade the phone software to a version earlier than 4.0.3, the phone cannot retain the call log details. Contact your administrator to enable the required settings to retain the call log details.

Turning call history on and off

Procedure

1. Press **Main menu > Settings > Phone settings**.
2. Use the **Down Arrow** key to go to the **Log recent calls** screen.
3. To toggle the call history feature on or off, do one of the following:
 - Select **Toggle**.
 - Use the **Left Arrow** and **Right Arrow** keys.
4. Press **Save**.

Viewing the Recents details

About this task

On the Recents screen, depending on the call type and the configuration to display the caller ID, you can view the details of each call. The following are a few examples:

- Incoming call icon
- Outgoing call icon
- Missed call icon
- Name
- Extension number
- Time
- Date
- Duration

 **Note:**

Duration is not available for a missed call.

Procedure

1. On the Phone screen, press one of the following:
 - **Main menu > Recents**
 - **Recents**

2. **(Optional)** On the **Recents** screen, use the **Right** and **left** arrow keys to scroll to the required call type.
3. Select the call that you want to view.
4. Press **Details**.

The phone displays the details of the selected call.

Managing a call record in the Recents list

Procedure

1. On the Phone screen, press one of the following:
 - **Main menu > Recents**
2. Select the number that you want to add or delete.
3. Select **Details**.
4. Select one of the following:
 - **+Contact**: To add a call record from the call history menu to the contacts list.
 - **Delete**: To delete a call record from the call history.

Clearing the Recents list

About this task

Use this procedure to delete all the call entries in the Recents list.

Before you begin

Ensure that your Recents list has at least one call record.

Procedure

1. On the Phone screen, press one of the following:
 - **Main menu > Recents**
 - **Recents**
2. Press **Clear All**.
3. Select one of the following when the phone prompts for confirmation:
 - **Clear All**: To delete all entries.
 - **Cancel**: To cancel and return to the previous menu.

Chapter 9: Conference calls

Adding a person to an active call

About this task

You can add participants to an active call to set up a conference call.

Before you begin

Start a call.

Procedure

1. During a call, on the Phone screen, press **More > Conf**.
The phone puts the existing call on hold.
2. To make a call to a participant, do one of the following:
 - Dial the phone extension by using the dial pad.
 - Call the person from the Contacts list or the Recents list.
3. When the third participant answers the call, press the **Join** soft key.
4. To add another person, press **Add** and repeat Steps 2 and 3.

Adding a person on hold to a conference call

About this task

Use this task to add a person that you have put on hold to a conference call.

Procedure

1. During an active call, press **Hold**.
2. Do one of the following:
 - To make a new call, press **NewCall** and dial the extension of the second person.
 - To answer an incoming call, press **Answer**.
 - To toggle between the calls, press **Swap**.
3. When the second person answers the call, press the **Conf > Merge** softkey.
The person on hold is added to the conference call.

Putting a conference call on hold and resuming a call

About this task

Use this procedure to put a conference participant on hold, while other participants continue the conference call.

Procedure

1. Press **Hold** button during a conference call.
2. Do one of the following:
 - Press **Resume**.
 - Select the call appearance to resume the conference call.

No Hold Conference

With the No Hold Conference feature, you can add participants to your call while continuing your active conversation. The No Hold Conference feature lets you create a conference call without putting any call participant on hold.

For example, if you press the administered **No Hold Conf** button and then dial an extension the participant that answers the call joins the no hold conference.

Using the **No Hold Conf** button you can add more participants to the no hold conference.

The administrator can pre-configure only one number on System Manager. When you press the **No Hold Conf** button, the call is placed to the pre-configured number when the participant answers the call joins the no hold conference.

If the participants do not answer the call within the configured time-out duration Avaya J100 Series IP Phones will display the appropriate message on the phone screen.

Related links

[Adding a participant to no hold conference](#) on page 41

Adding a participant to no hold conference

About this task

You can add participants to your call while continuing your conversation without interruption. You can add up to six participants in the no hold conference call.

Before you begin

Ensure that your administrator activates the no hold conference feature and feature target selection.

Ensure that you are on a call.

Procedure

1. During an active call, on the phone screen, press **Main menu > Features**.
2. Press **No Hold Conference**.
Select a destination dialogue box is displayed.
3. You can add users to a no hold conference by using one of the following methods:
 - If an extension number is pre-configured by your administrator, you can press **Select**.
 - If the extension number is not pre-configured, press the **Dial** soft key to use the dialpad and manually enter the extension number, press **OK**.
 - Press **Contacts**, **Recents** or **Phone** button to select the number from the list.
 - Press the **Browser** soft key to select the destination number from the browser application.
 - Press the **Autodial**, **Busy indicator** or **Team** line key to select the number as destination target.

The no hold conference feature is activated.

4. To add more participants to the existing no hold conference, repeat Steps 2 and 3.

 **Note:**

You can press the **Cancel** soft key to terminate the no hold conference.

5. Press **Enter** or **OK** to activate the feature in case of manual dialling.

Related links

[No Hold Conference](#) on page 41


[Handling calls and conferences using Multiple Device Access](#) on page 50

Chapter 10: Call related features

Muting and unmuting a call

About this task

In an active call, use the Mute button to cut off all the audio transmission from your phone. When you enable this feature, the phone illuminates the Mute button, and you can hear the caller, but the caller cannot hear you. When the mute feature is active for a while and, if you talk, the phone

plays an audio mute-alert notification, with a flickering mute icon  on the phone screen. Initially, the phone notifies with an audio and visual alert, followed by only the visual alert if you continue talking on an active mute until you unmute the call.

Procedure

1. To mute an active call, press the **Mute** button.
The phone illuminates the **Mute** button immediately.
2. To unmute the call, press the **Mute** button again.

Placing a call on hold and resuming the call

About this task

During a call, you can place the call on hold. When you put a call on hold, both you and the caller cannot hear each other on the call. While a call is on hold, you can call other contacts. When multiple calls are held, you can return to the held call by using the up and down arrow keys to scroll to the required call.

Procedure

1. To put an active call on hold, press the **Hold** soft key.
2. To resume the held call, press the **Resume** soft key, or press the line key of the held call.

Resuming a held call by using Hold button

About this task

You can resume a held call by using the hold button.

Before you begin

Ensure you have an active held call on the phone.

Procedure

Press **Hold** button to resume the held call.

When you have multiple held calls and you are on the phone screen, pressing the hold button will:

- Resume the highlighted held call, if the held call is highlighted
- Resume the last held call, if there is no highlighted held call

If you are not on the phone screen, pressing hold button will:

- Resume the last held call
- Redirect you to the phone screen, and cancel any other action on the user input menu

Off-hook alert

When enabled by your system administrator, this feature allows your phone to send alerts to a monitoring phone when it is off the hook for a set period of time with no action on user side. The phone sends alerts in the following cases:

- If you take the handset off the hook and do not dial any digits for a set period of time and then do not end the failed session.
- If you take the handset off the hook, dial an incomplete or invalid phone or extension number, and do not end the failed session after a set period of time.

When the phone dials the off-hook alert destination extension, the call can be picked up and you will have a two-way talk path with the monitoring party.

Chapter 11: Do not disturb and Call Forward

Do not disturb

You can use the Do not disturb feature to avoid audio notifications for all direct incoming calls. The phone redirects these incoming calls to a predefined coverage number that your system administrator sets. The feature is also referred to as Send all calls. If required, contact your administrator to name this feature on your phone as Send all calls.

Related links

[Activating and deactivating Do not disturb](#) on page 45

Activating and deactivating Do not disturb

About this task

You can activate the Do not disturb feature to prevent the phone from ringing when you get a call. The phone redirects the direct incoming calls to a predefined coverage number that your system administrator sets.

In the IP Office environment, this feature is supported using short code dialing. Contact your system administrator for the list of short codes.

Before you begin

Your system administrator must activate the feature for your extension.

Procedure

1. Press **Main menu > Features**.
2. Use the **Down Arrow** key to go to the Do not disturb screen.
3. Select **Do not disturb** to activate or deactivate the feature.

Related links

[Do not disturb](#) on page 45

Call forwarding

Use the Call forwarding feature to divert incoming calls to another number when you cannot answer the calls. For example, if the call forwarding feature is active on your phone, when you receive a call, the phone redirects this call to the forwarding number. Depending on your requirements, your system administrator enables the feature and configures the call forwarding options.

The following are the available Call forwarding options:

- **Call forward:** Diverts all incoming calls to another number.
- **Call forward Busy:** Diverts incoming calls to another number if you are on a call.
- **Call forward No Answer:** Diverts incoming calls to another number if you do not answer the calls within the set time interval.

The phone does not support all the call forwarding options active simultaneously. You can enable the call forwarding option to forward all calls or, the options call forward busy and no answer.

Enhanced Call forward

Use the enhanced call forwarding feature to divert incoming calls to different numbers depending on the source. Set the rules as per your requirements to forward the internal and external incoming calls. Enter the internal and external phone numbers in the corresponding Call forwarding option.

Forwarding a call to another extension

About this task

Use this procedure to forward incoming calls to the required extension.

In the IP Office environment, use the short code dialing for the call forwarding feature. Contact your system administrator for the list of short codes.

Before you begin

Ensure that your administrator enables the feature and the required call forwarding options. Ensure that feature target selection is also enabled.

Procedure

1. Press **Main menu**.
2. Scroll to **Features** and press **Select**.
3. To enable the Call Forward feature, scroll to one of the following options:
 - **Call Forward:** to forward all incoming calls to another number.
 - **Call Forward-Busy:** to forward incoming calls to another number if you are on a call
 - **Call Forward-No Answer:** to forward incoming calls to another number if you do not answer the call within the set time interval.

Call Forward-Busy and Call Forward-No Answer options are available when your administrator configures it.

4. Press **Select**.

You can see the **Select a destination** dialogue box.

5. Do one of the following to enter the number where you want to forward the incoming calls:

- Press the **Dial** soft key to use the dialpad and manually enter the number.
- Press **Contacts**, **Recents** or **Phone** button to select the number from the list.
- Press the **Browser** soft key to select the destination number from the browser application.
- Press the **Autodial**, **Busy indicator** or **Team** line key to select the number as destination target.

Call Forward feature is activated.

6. Press **Enter** to activate the call forward feature in case you manually dial the extension number.

The phone generates a confirmation tone and returns to the Features screen.

7. **(Optional)** To cancel the feature, press the **Cancel** soft key.8. To disable any Call Forward option, go to the active Call Forward option and press **Select**.

Activating EC500

About this task

Use this procedure to answer calls on your cell phone.

This feature is only available in the Avaya Aura[®] environment.

Before you begin

The system administrator must program the phone so that you can receive incoming calls on your cell phone.

Procedure

1. Press **Main menu > Features**.
2. Use the **Down Arrow** key to go the EC500 screen.
3. Press **OK**.

Chapter 12: Advanced features

You can access advanced features available on your phone from the Features screen.

Accessing the Features screen

About this task

Use this procedure to access the Features screen.

Procedure

1. Press **Main menu** and scroll to **Features**.
2. Press **Select**.
3. Scroll to see the features that are configured for your extension.

Activating transfer to voice mail

About this task

Use this procedure to transfer an active call to voice mail.

Before you begin

Your system administrator must activate the feature for your extension.

This feature is only available in the Avaya Aura[®] environment.

Procedure

1. During an active call, press **Main menu > Features**.
2. Use the **Down Arrow** key to go to the Transfer to VM screen.
3. Press **Select** or **OK** to activate the transfer to voice mail.

Blocking your extension from displaying during calls

About this task

This feature is only available in an Avaya Aura® environment.

Before you begin

Ensure that the system administrator activates the option for your extension.

Procedure

1. Press **Main menu > Features**.
2. Select **CPN block**.
3. In the **Destination** field, enter the extension number that you do not want the called party to see.
4. Press **OK**.

Intercom

You can answer an auto intercom call, if your administrator configures an auto intercom button for your phone.

Multiple Device Access

With the Multiple Device Access (MDA) feature, you can register up to 10 SIP devices with the same extension to transfer active calls between devices.

This feature is available only in an Avaya Aura® environment. Multiple Device Access is configured on Avaya Aura® Session Manager.

MDA limitations

There are limitations for Multiple Device Access as Avaya J129 IP Phone supports only two call appearances, while the user might have more than two call appearances configured.

The limitations for Multiple Device Access are the following:

- There is no audio or visual alerting for the third incoming call if two call appearances are already in use.
- The Avaya J129 IP Phone will not display the third or higher call appearance.
- When you receive an MDA indication, press the **Phone** button to view the details and join the bridged call.

Handling calls and conferences using Multiple Device Access

About this task

With the Avaya Aura® and Multiple Device Access feature, you can have up to ten devices configured with the same extension number. You can use this extension number to transfer active calls between your devices.

Before you begin

Ensure that the system administrator has activated the Multiple Device Access feature (MDA) for your extension.

Procedure

1. Initiate a call from your phone.
2. To transfer the call to another phone, press **Bridge** on your phone.

If the MDA phone that is joining the call uses a different signaling mode address family, you might notice the Limited Service icon appear on your device for a brief moment. After the MDA phone that is joining the call switches to using the signaling mode address family of the active call, the icon disappears.

Related links

[Adding a participant to no hold conference](#) on page 41

Multicast Paging

With the Multicast Paging feature, you can receive a page that will be automatically played on the phone. If configured by the system administrator, you can send a multicast page to a group of phones in the network.

An incoming multicast page is played on the phone speaker. When the page is played, the Phone screen displays the `Page from <group name>` notification during the whole time of transmission.

All configured multicast groups that you can send a page to are available in the Features menu. You can add, move or delete the multicast page keys from the Phone screen by the common customization procedure.

Active calls with a lower priority than the multicast page are put on hold, all lower-priority incoming calls are ignored.

A multicast page is ignored if the agent is on an active call and has the Do Not Disturb status, or making an emergency call.

Sending a multicast page

About this task

You can send a multicast page to a group of users by activating the Multicast Paging group on the Phone screen. If the required group is not added on this screen, you can access all multicast page groups configured for your phone in the Features menu.

Procedure

1. Do one of the following:
 - Lift the handset.
 - Press **Speaker**.
2. On the Phone screen, scroll to the required multicast page group, and press **Select**.
The phone displays the `Paging <group name> box`.
3. To end the multicast page, do one of the following:
 - Press **End Call**.
 - If you use the handset as an audio device, hang up.

Parking and unparking a call

About this task

Use this procedure to park the active call and answer the call from another extension.

This feature is only available in the Avaya Aura® environment.

Your system administrator must activate the feature for your extension.

In the IP Office environment, this feature is supported using short code dialing. Contact your system administrator for the list of short codes.

Procedure

1. While on an active call, press **Main menu > Features**.
2. Use the **Down Arrow** key to go to the Call Park screen.
3. Press **Select** or **OK**.
The phone parks the call.
4. To answer a parked call, press **Main menu > Features**.
5. Use the **Down Arrow** key to go to the Call Unpark screen.
6. Press **Select** or **OK**.
7. Enter the extension from which the call was parked.

8. Press **OK**.

The phone un parks the call.

Making an attended transfer

About this task

An attended transfer is when you put an active call on hold and establish a second call with the call-transfer recipient before transferring the call.

Procedure

1. Do one of the following:

- Use the keypad to dial the number to which you want to transfer the call .
- Call the person from the Contacts list or the Recents list.

The first call is put on hold, and the recipient's phone starts ringing.

2. Press the **Complete** softkey after the recipient answers the call.

The phone transfers the call to the selected number.

Making an unattended transfer

About this task

An unattended transfer is when you transfer an active call without establishing a call with the call-transfer recipient.

Procedure

1. Do one of the following:

- Use the keypad to dial the number to which you want to transfer the call.
- Call the person from the Contacts list or the Recents list.

The first call is put on hold, and the recipient's phone starts ringing.

2. To complete the transfer, press the **Complete** softkey.

The phone transfers the call to the selected number.

If the called party does not answer the call, then the unanswered call returns to your phone as a recalled transfer call.

Setting up automatic call back

About this task

When an extension is busy, use this procedure to receive a call back automatically after the extension is free.

In the IP Office environment, this feature is supported using short code dialing. Contact your system administrator for the list of short codes.

Before you begin

Your system administrator must activate the feature for your extension.

Procedure

1. During an outgoing call to far end, when the line is busy, press **Main menu > Features**.
2. Use the **Down Arrow** key to go to the Auto Callback screen.
3. Press **Select** or **OK** to activate **Auto Callback**.

When you end the callback call, the system deactivates the feature automatically.

Shared control

With the Shared Control feature, you can operate phones from the Avaya Workplace Client and use high-quality audio of the phone. All the Avaya J100 Series IP Phones models support the Shared control feature.

Ensure that your phone is registered with Avaya Aura® to establish a shared control connection. When you log in to your phone and Avaya Workplace Client in the shared control mode, you can control the phone through Avaya Workplace Client. You might not establish a shared control session if multiple devices are registered to the same user, depending on the client implementation.

Your system administrator activates the Shared Control feature and configures it on Avaya Workplace Client.

Note:

This feature is available only in the Avaya Aura® environment.

You can perform the following tasks on the Avaya J100 Series IP Phones:

- make a call
- answer a call
- place and resume a call on hold
- mute and unmute a call
- call transfer
- conference

Notifications

You see the following messages on your e-Phone screen after the phone is configured or disconnected from Avaya Workplace Client:

- Shared Control active
- Shared Control inactive

For information on installing and configuring Avaya Workplace Client, see *Planning for and Administering Avaya Workplace Client for Android, iOS, Mac, and Windows* and *Using Avaya Workplace Client for Android, iOS, Mac, and Windows* at <https://support.avaya.com/>.

Tracing a malicious call

About this task

Use this procedure to activate Malicious Call Tracing and providing information about the malicious call. This feature is available only if your administrator has set up the phone system to trace and track malicious calls and there is an attendant or controlling user to oversee the trace. This feature is only available in an Avaya Aura[®] environment.

Before you begin

Your system administrator must activate the feature for your extension.

Procedure

1. During an active call, press **Main menu > Features**.
2. Use the **Down Arrow** key to go to the MCT Act screen.
3. Press **OK**.

An alerting tone or flashing beacon LED indicates that the trace is active. Hanging up deactivates MCT Act.

Voicemail

You can use the Voicemail feature on your phone with a voice messaging service such as Avaya Messaging. Your system administrator enables the Voicemail feature and configures your voicemail number and password. The beacon LED on your phone lights when you receive a voicemail. Listen to and follow the audio prompts to perform the required action on the voicemail.

If your voice messaging service provides the web interface feature, you can access voicemail on your computer. Contact your system administrator for voicemail web interface feature details.

Listening to your voicemail

About this task

Use this procedure to listen to your voicemail on your phone.

Before you begin

- Ensure that the system administrator configures the voicemail for your extension.
- Obtain the user ID and password of your voicemail from your system administrator.

Procedure

1. Press **Main menu**.
2. Use the **Down Arrow** key to go to the Voicemail screen.
3. Press **Select**.
4. Follow the voice prompts to playback your voice messages.

Chapter 13: Phone customization

Phone

Setting the Dial mode

About this task

Use this procedure to set the dialing method used to initiate dialing.

Procedure

1. Press **Main menu > Settings > Phone settings**.
2. Use the **Down Arrow** key to go to the Dial mode screen.
3. Press **Toggle** to select one of the following :
 - **Manual**: Press the **Call** softkey to start a call.
 - **Auto**: The dialed digits must match the dialplan to start a call.
 - **Default**: Press the **Call** soft key to start a call.
4. Press **Save**.

Displaying call timers

About this task

Use this procedure to display the duration of calls.

Procedure

1. Press **Main Menu**.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Phone settings**, and press **Select**.
4. Use the **Down Arrow** key to go to the **Display call timers**.
5. Press **Toggle** to activate or deactivate the call timers.
6. Press **Save**.

Assigning Speed Dial

About this task

Use this procedure to assign speed dial numbers to your contacts. You can assign up to nine speed dial entries.

Procedure

1. Press **Main menu** > **Settings** > **Phone settings**.
2. Select **Speed Dial**.
3. Use the **Up** and **Down Arrow** keys to select a Speed Dial number.
4. Press **Contacts** to select a contact.
5. Press **Select** to assign the contact to the selected Speed Dial number.

You can assign only one contact to a Speed dial number.

Replacing and clearing a Speed Dial contact

About this task

Use this procedure to replace or remove a Speed Dial contact.

Before you begin

Assign a contact to a Speed Dial number.

Procedure

1. Press **Main menu** > **Settings** > **Phone settings**.
2. Select **Speed Dial**.
3. Use the **Down Arrow** key to go to the Speed Dial contact that you want to replace or clear.
4. Press one of the following:
 - **Replace**: To replace the contact with another contact.
 - **Clear**: To remove the contact from the Speed Dial.
5. Press **Replace** or **Clear** when the phone prompts for confirmation.

Activating Mute Alert

About this task

Use this procedure to configure your phone to alert if you speak while your phone is on mute.

Before you begin

Ensure that the system administrator activates the option for your extension.

Procedure

1. Press **Main menu** > **Settings** > **Phone settings**.

2. Use the **Down Arrow** key to go to the Mute alert screen.
3. Press **Toggle** to select one of the following:
 - **Audible**: If you put a call on mute and start speaking after eight seconds, the phone produces a beep to notify that you are on mute.
 - **Visual**: If you put a call on mute and start speaking after eight seconds, the phone displays the Call Muted icon.

*** Note:**

If the user stops talking while mute alerting is on, after a delay of 500 milliseconds, the call muted icon is replaced by the normal active call icon

- **Both**: Combines the actions of both audible and visual alerting.
 - **None**: Disables the mute alert for your phone.
4. Press **Save**.

Mute alert turns off automatically when you take the call off mute.

Visual alerting

The beacon LED works in the following manner to indicate incoming calls and messages:

- If there is an incoming call, the beacon LED blinks.
- If new voicemail messages exist, the beacon LED is lit continuously.
- If the speaker is on during an active call and there are new voicemail messages, the beacon LED turns off every 15 seconds.
- If the call is on hold, the beacon LED stops flashing.

When the call is on speaker, the speaker icon () replaces the active call handset () icon.

Related links

[Setting Visual alerting](#) on page 58

Setting Visual alerting

About this task

The phone illuminates the beacon LED when there are incoming calls and messages. Use this procedure to enable the visual alerting.

Procedure

1. Press **Main Menu**.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Phone settings**, and press **Select**.
4. Scroll to **Alerting on calls**, and press **Select**.

5. Scroll to **Beacon LED**.
6. Press **Toggle** to enable or disable visual alerting.
7. Press **Save**.

Related links

[Visual alerting](#) on page 58

Audio

Setting a ring tone for incoming calls

Procedure

1. Press **Main menu > Settings > Audio settings**.
2. Select **Personalize ringing**
3. Use the **Down Arrow** key to select **Ring Type**.
4. Press **Select** to choose the required ring tone.
5. Press **Save**.

Turning button clicks on and off

Procedure

1. Press **Main menu > Settings > Audio settings**.
2. Scroll to Button clicks and press **Toggle** to turn the audio on or off.
3. Press **Save**.

Turning error tones on and off

About this task

You can activate the error tone alarm when you perform an incorrect action while using the phone with this feature.

Procedure

1. Press **Main menu > Settings > Audio settings**.
2. To turn error tones on or off, scroll to **Error tones** and press **Toggle**.
3. Press **Save**.

Turning audio settings on and off

About this task

Automatic gain control (AGC) raises the volume when a caller is speaking in a low voice and lowers the volume when the caller is speaking aloud. Use this procedure to turn AGC on or off separately for the headset and speaker.

Procedure

1. Press **Main menu** > **Settings** > **Audio settings**.
2. Select **AGC**.
3. Use the **Up** and **Down Arrow** keys to select the headset or speaker for which you want to turn AGC on or off.
4. Press **Select** to turn the headset or speaker on.
5. Press **Save**.

Setting Handset Profile

About this task

The task is relevant for people with hearing difficulties. Use this procedure to change the audio characteristic of the phone.

Procedure

1. Press **Main menu** > **Settings** > **Audio settings**.
2. Select **Handset Profile**.

The phone displays the following:

- **Default**
 - **Normal**
 - **Amplified**: Extends the maximum volume beyond the normal audio level. The option must be used with care because long term extended use of the highest volume settings can cause ear damage.
 - **Hearing Aid**: Optimizes the sound quality of hearing aids.
3. Press **Select** to choose one of the options.
 4. Press **Save**.

Sidetone of your handset

Sidetone is the ambient noise you can hear as feedback when you speak using the handset of your phone. To adjust the level of this feedback noise, contact your system administrator.

Display

Adjusting the contrast of the display screen

Procedure

1. Press **Main menu > Settings > Display settings**.
2. Scroll down to **Contrast**.
3. Press **Select**
4. Press one of the following:
 - **Right Arrow** key: To increase the contrast.
 - **Left Arrow** key: To decrease the contrast.
5. Press **Save**.

Setting the display language

Procedure

1. Press **Main menu > Settings > Display settings**.
2. Select **Language**.
3. Scroll to the language , and press one of the following:
 - **Select**
 - **OK**

The phone prompts for the confirmation.

4. Press one of the following:
 - **Yes**
 - **OK**

The phone returns to the Display Settings screen and the language changes to the selected language.

Setting the date format

Procedure

1. Press **Main menu > Settings > Display settings**.
2. To go to the Date format screen, use the **Down Arrow** key.

The phone displays one of the following:

- **Default**
- **mm/dd**

- **dd/mm**
 - **mm.dd**
 - **dd.mm**
 - **mm-dd**
 - **dd-mm**
 - **mmm dd**
3. To select one of the options, press **Toggle**.
 4. Press **Save**.

Setting the time format

Before you begin

Ensure that your administrator has enabled the time format feature.

Procedure

1. Press **Main menu > Settings > Display settings**.
2. Use the **Down Arrow** key to go to the Time format screen.
3. Press **Toggle** to select one of the following options:
 - **Time format 24 Hour**
 - **Time format 12 Hour**
4. Press **Save**.

Setting the time zone

About this task

Use this procedure to set the current time of the phone.

Procedure

1. Press **Main menu > Settings > Display settings**.
2. Scroll to **Time zone** and press **Select**.
3. To set the required time, do one of the following:
 - Use the **Left Arrow** and **Right Arrow** keys.
 - Press - or + soft key.
4. Press **Save**.

Backup and restore

Backup and restore overview

The phone supports the backup and restoration of the following user-specific data:

- User contacts
- Local ring type
- Local Do Not Disturb status
- Local call forward settings
- Auto-answer mode configuration
- Speed dial settings
- Language
- Time zone and time format
- Date format
- Customized phone key labels

Backup process is initiated only after retrieval of user-specific data is successful.

Backing up and restoring data

Before you begin

Ensure that the system administrator sets the URI for backup and restore.

Procedure

1. Press **Main menu** > **Settings**.
2. Use the **Down Arrow** key to go the Backup/Restore screen.
3. Press **Select**.
4. Press **Select** again to select one of the following:
 - **Manual Backup**
 - **Manual Restore**

The phone displays the following messages and returns to the previous screen.

- When **Manual Backup** is not successful: Backup failed
- When **Manual Backup** is successful: Backup successful
- When **Manual Restore** is not successful: Retrieval failed
- When **Manual Restore** is successful: Retrieval successful

Chapter 14: Phone update

Updating your phone

Before you begin

When the phone is ready for an update, depending on your administrator settings, the phone screen prompts you to confirm the restart of your phone immediately. You can choose to update your phone or cancel the update. When you cancel, the phone prompts you again in the next update cycle as set by your administrator.

Before you begin

Ensure that your administrator provides you access to confirm the phone restart.

Procedure

1. The pop-up screen on the phone displays `New firmware available, restart the phone to apply changes?`
2. Press **Restart**.

Checking your phone periodic automatic update

About this task

Your system administrator sets to update your phone automatically. To know when your phone is due for an update or frequency of the update, use this procedure.

Before you begin

Ensure that your administrator enables the periodic automatic update feature.

Procedure

1. Press **Main Menu**.
2. Scroll to **Network Information** and press **Select**.
3. Scroll to **Automatic update** and press **Select**.

The Automatic update screen shows the following:

- **Automatic update policy:** Displays the frequency of the phone update set by your administrator.

- **Last update:** Displays the date and time of the last update of the phone.
- **Next update:** Displays the date and time of the next update of the phone.

Chapter 15: Maintenance

Viewing the product ID

About this task

The product ID information is available on a label on the back panel of your phone. Alternatively, you can view and verify the product ID on the phone screen.

Procedure

1. Press **Main Menu**.
2. Scroll to **Network information** and press **Select**.
3. Scroll to **System** and press **Select**.
4. Scroll to **Product ID**.

Viewing the device type

About this task

View your device type when your system administrator asks you to provide your device type information. The device type can be Avaya SIP or Open SIP.

Procedure

1. Press **Main Menu**.
2. Scroll to **Network information** and press **Select**.
3. Scroll to **System** and press **Select**.
4. Scroll to **Device type**.

Viewing the secondary provisioning server address

About this task

View the secondary provisioning server address when your system administrator asks you to provide the server details. The phone administrators can configure a secondary provisioning server to provide additional phone settings.

Before you begin

Ensure that the administrator configures a secondary provisioning server for your phone.

Procedure

1. Press **Main Menu**.
2. Scroll to **Network information** and press **Select**.
3. Scroll to **IP parameters** and press **Select**.
4. Scroll to **Custom URL**.

The **Custom URL** field displays the secondary provisioning server URL.

Viewing the server type

About this task

View your server type when your system administrator asks you to provide your server type information. The server type can be either Avaya Aura® or Open SIP.

Procedure

1. Press **Main Menu**.
2. Scroll to **Network information** and press **Select**.
3. Scroll to **System** and press **Select**.
4. Scroll to **Server type**.

Chapter 16: Resources

Documentation

For Avaya J100 Series IP Phones documents of previous releases, visit the Avaya Support site at <http://support.avaya.com>:

- [4.1.x](#)
- [4.0.x](#)
- [3.0.x](#)

See the following related documents for the Avaya J100 Series IP Phones at <http://support.avaya.com>:

Title	Use this document to:	Audience
Overview		
<i>Avaya Aura® Session Manager Overview and Specification</i>	See characteristics and capabilities, including feature descriptions, interoperability, performance specifications, security, and licensing requirements of the Avaya Aura® Session Manager.	People who want to gain a high-level understanding of the Avaya Aura® Session Manager features, functions, capacities, and limitations.
<i>Avaya Aura® Communication Manager Feature Description and Implementation</i>	See characteristics and capabilities, including feature descriptions, interoperability, performance specifications, security, and licensing requirements of the Avaya Aura® Communication Manager.	People who want to gain a high-level understanding of the Avaya Aura® Communication Manager features, functions, capacities, and limitations.
<i>Avaya IP Office™ Platform Feature Description</i>	See information about the feature descriptions.	People who perform system administration tasks.

Table continues...


Title	Use this document to:	Audience
<i>Avaya IP Office™ Platform Solution Description</i>	See information about how the products and services interoperate with this solution.	People who want to gain a high-level understanding of the IP Office features, functions, capacities, and limitations.
Implementing		
<i>Deploying Avaya Aura® Session Manager</i>	See the installation procedures and initial administration information for Avaya Aura® Session Manager.	People who install, configure, and verify Avaya Aura® Session Manager on Avaya Aura® System Platform.
<i>Upgrading Avaya Aura® Session Manager</i>	See upgrading checklists and procedures.	People who perform upgrades of Avaya Aura® Session Manager.
<i>Deploying Avaya Aura® System Manager on System Platform</i>	See the installation procedures and initial administration information for Avaya Aura® System Manager.	People who install, configure, and verify Avaya Aura® System Manager on Avaya Aura® System Platform at a customer site.
<i>IP Office SIP Telephone Installation Notes</i>	See the installation procedures and initial administration information for IP Office SIP telephone devices.	People who install, configure and verify SIP telephone devices on IP Office.
Administering		
<i>Administering Avaya Aura® Session Manager</i>	See information about performing Avaya Aura® Session Manager administration tasks, including how to use management tools, how to manage data and security, and how to perform periodic maintenance tasks.	People who perform Avaya Aura® Session Manager system administration tasks.
<i>Administering Avaya Aura® System Manager</i>	See information about performing Avaya Aura® System Manager administration tasks, including how to use management tools, how to manage data and security, and how to perform periodic maintenance tasks.	People who perform Avaya Aura® System Manager administration tasks.
<i>Administering Avaya IP Office™ Platform with Manager</i>	See information about short code configurations for the feature list	People who need to access IP Office features using short codes.

Table continues...

Title	Use this document to:	Audience
<i>Administering Avaya IP Office™ Platform with Web Manager</i>	See information about IP Office Web Manager administration tasks, including how to use the management tool, how to manage data and security, and how to perform maintenance tasks.	People who perform IP Office Web Manager administration tasks.
Maintaining		
<i>Maintaining Avaya Aura® Session Manager</i>	See information about the maintenance tasks for Avaya Aura® Session Manager.	People who maintain Avaya Aura® Session Manager.
<i>Troubleshooting Avaya Aura® Session Manager</i>	See information for troubleshooting Avaya Aura® Session Manager, resolving alarms, replacing hardware, alarm codes, and event ID descriptions.	People who troubleshoot Avaya Aura® Session Manager.
<i>Using IP Office System Status</i>	See information about the maintenance tasks for System Status Application.	People who maintain System Status Application.
<i>Using IP Office System Monitor</i>	See information about the maintenance tasks for SysMonitor.	People who maintain SysMonitor.

Finding documents on the Avaya Support website

Procedure

1. Go to <https://support.avaya.com>.
2. To log in, click **Sign In** at the top of the screen and then enter your login credentials when prompted.
3. Click **Product Support > Documents**.
4. In **Search Product**, start typing the product name and then select the appropriate product from the list displayed.
5. In **Select Release**, select the appropriate release number.
This field is not available if there is only one release for the product.
6. **(Optional)** In **Enter Keyword**, type keywords for your search.
7. From the **Select Content Type** list, select one or more content types.
For example, if you only want to see user guides, click **User Guides** in the **Select Content Type** list.
8. Click  to display the search results.

Avaya Documentation Center navigation

For many programs, the latest customer documentation is available on the Avaya Documentation Center website at <https://documentation.avaya.com>. Some functionality is only available when you log in to the Avaya Documentation Center. The available functionality depends on your role.

Important:

If the documentation you are looking for is not available on the Avaya Documentation Center, you can find it on the [Avaya Support website](#).

While navigating through the Documentation Center, you can click the **Avaya Documentation Center** logo at the top of the screen to return to the home page anytime. On the Avaya Documentation Center, you can do the following:

- Click **Avaya Links** in the top menu bar to access other Avaya websites, including the Avaya Support website.
- Click **Languages** (🌐) in the top menu bar to change the display language and view localized documents.
- In the **Search Documentation** field, search for keywords and click **Filter** to filter by solution category, product, or user role.
You can select multiple items in each filter category. For example, you can select a product and multiple user roles.
- Click **Library** in the top menu bar to access the complete library of documents. Use the filtering options to refine your results.
- After performing a search or accessing the library, you can sort content on the search results page. When you find the item you want to view, click it to open it.
- Use the table of contents in a document for navigation. You can also click < or > next to the document title to navigate to the previous topic or the next topic.
- Click **Share** (➦) to share a topic by email or copy the URL.
- Download a PDF of the current topic in a document, the topic and its subtopics, or the entire document.
- Print the section you are viewing.
- Add content to a collection by clicking **Add to My Topics** (📌). You can add the topic and its subtopics or add the entire publication.
- View the topics in your collections. To access your collections, click your name in the top menu bar and then click **My Topics**.

You can do the following:

- Create, rename, and delete a collection.
- Set a collection as the default or favorite collection.
- Save a PDF of the selected content in a collection and download it to your computer.

- Share content in a collection with others through email.
- Receive collections that others have shared with you.
- Click **Watch** (👁) to add a topic to your watchlist so you are notified when the content is updated or removed.
- View and manage your watchlist by clicking **Watchlist** from the top menu with your name.
You can do the following:
 - Enable **Email notifications** to receive email alerts.
 - Unwatch the selected content or all topics.
- Send feedback for a topic.

Viewing Avaya Mentor videos

Avaya Mentor videos provide technical content on how to install, configure, and troubleshoot Avaya products.

About this task

Videos are available on the Avaya Support website, listed under the video document type, and on the Avaya-run channel on YouTube.

- To find videos on the Avaya Support website, go to <https://support.avaya.com/> and do one of the following:
 - In **Search**, type `Avaya Mentor Videos`, click **Clear All** and select **Video** in the **Select Content Type**.
 - In **Search**, type the product name. On the Search Results page, click **Clear All** and select **Video** in the **Select Content Type**.

The **Video** content type is displayed only when videos are available for that product.

In the right pane, the page displays a list of available videos.

- To find the Avaya Mentor videos on YouTube, go to www.youtube.com/AvayaMentor and do one of the following:
 - Enter a keyword or keywords in the **Search Channel** to search for a specific product or topic.
 - Scroll down Playlists, and click a topic name to see the list of videos available. For example, Contact Centers.

 **Note:**

Videos are not available for all products.

Support

Go to the Avaya Support website at <https://support.avaya.com> for the most up-to-date documentation, product notices, and knowledge articles. You can also search for release notes, downloads, and resolutions to issues. Use the online service request system to create a service request. Chat with live agents to get answers to questions, or request an agent to connect you to a support team if an issue requires additional expertise.

Index

A

- adding
 - contacts [34](#)
- administrative methods
 - file server address [15](#)
 - provisioning server [15](#)
- AGC
 - audio settings [60](#)
 - settings [60](#)
- answering a call
 - when on another call [26](#)
- audio
 - feedback [60](#)
- audio settings
 - AGC [60](#)
 - button clicks [59](#)
 - error tones [59](#)
 - Handset Profile [60](#)
 - ring type [59](#)
 - settings [59, 60](#)
- automatic callback
 - calls [53](#)
- automatic update
 - phone firmware [64](#)
 - settings update [64](#)
- Avaya support website [73](#)

B

- back-panel [11](#)
- backing up
 - manual backup [63](#)
 - manual restore [63](#)
- blind transfer [52](#)
- block incoming calls [17](#)
- button clicks
 - turn off [59](#)
 - turn on [59](#)

C

- call
 - recents [31](#)
- call forward,
 - disable [46](#)
 - enable [46](#)
- call forwarding
 - call forward busy [46](#)
 - call forward no answer [46](#)
- call history
 - adding a contact [39](#)
 - deleting a call record [39](#)

- call history (*continued*)
 - viewing [38](#)
- call transfer
 - attended [52](#)
 - unattended [52](#)
- calling
 - corporate database list [31](#)
 - dial pad [30, 31](#)
 - emergency calling [32](#)
 - local contacts list [30](#)
 - Main Menu [30](#)
- calls
 - attended transfer [52](#)
 - automatic callback [53](#)
 - beacon LED [58](#)
 - call parking [51](#)
 - call unparking [51](#)
 - e.164 dialing [33](#)
 - editing a contact [35](#)
 - hold [43](#)
 - ignoring [27](#)
 - incoming call [26](#)
 - international [33](#)
 - MCT [54](#)
 - multiple device access [50](#)
 - Mute Alert [57](#)
 - muting a call [43](#)
 - MWI [58](#)
 - resume [43](#)
 - speed dialing [30](#)
 - switching phone [50](#)
 - toggling [30](#)
 - transferring call [28](#)
 - unmuting a call [43](#)
 - visual alerting [58](#)
- collection
 - delete [71](#)
 - edit [71](#)
 - generating PDF [71](#)
 - sharing content [71](#)
- conference calls
 - putting a call on hold [41](#)
 - setting up [40](#)
- Conference Calls
 - adding a person on hold [40](#)
- conference, add participant using no hold conference [41](#)
- configuring provision server
 - file server address [15](#)
- connecting
 - hidden Wi-Fi [20](#)
 - Wi-Fi [20](#)
- connecting network
 - automatically [19](#)

connecting network (<i>continued</i>)		error tones (<i>continued</i>)	
manually	19	turn off	59
contacts		turn on	59
adding	34	F	
adding a contact from call history	39	features	
deleting	36	accessing features	48
deleting a contact from call history	39	advanced	48
editing	35	automatic callback	53
last name	35	call forward	46
new contact	34	multiple device access	49
searching	31, 35	tracing malicious call	54
speed dialing	30, 57	transfer to voice mail	48
content		finding content on documentation center	71
publishing PDF output	71	H	
searching	71	Handset Profile	
sharing	71	Amplified	60
sort by last updated	71	audio settings	60
watching for updates	71	default	60
D		Hearing Aid	60
deleting		normal	60
removing a contact	35	hold	
details		putting a conference call on hold	41
contacts	35	toggling	30
device type		Hold button	
Avaya SIP	66	resume call	44
Open SIP	66	hotline	49
Dial mode		I	
automatic dialing	56	icom	
manual dialing	56	autoicom	49
display contrast	61	icons	22
display settings		identifying	
date format	61	device type	16
language	61	ignoring	
time format	62	incoming calls	27
time zone	62	incoming call	
do not disturb		audio alert	26
DND	45	visual alert	26
send all calls	45	incoming calls	25
documentation center	71	do not disturb	45
finding content	71	EC500	47
navigation	71	enabling call forward	46
documentation portal	71	send all calls	45
E		intercom	
editing		automatic intercom	49
contacts	35	L	
local contact details	35	local contacts	
emergency calling		details	35
dial pad	32	lock	
Emerg	32		
lock screen	32		
status screen	32		
emergency calls	17		
error tones			

lock (<i>continued</i>)	
unlock	17
log	
calls	37
encryption	37
Logging in to your phone extension	16

M

main menu	
features	48
language	61
Main Menu	22
making a call	
auto	29
dial mode	29
manual	29
recents	31
using the dial mode	29
messages	
visual alerting	58
missed call	
viewing call details	27
Multicast Paging	
overview	50
sending a multicast page	51
multiple device access	
handling calls	50
handling conference	50
limitations	49
mute	
Mute Alert	57
Mute Alert	
calls	57

N

network settings	
configuration	19
mode	18
no hold conference	41
no hold conference, add participant	41

O

off-hook alert	44
outgoing calls	
blocking extension display	49
international	33
redialing a number	29
overview	44
call forwarding	46
feature specifications	9
physical specifications	9

P

periodic update	
phone firmware	64
phone	
boot-up	16
calls	25
inbound	25
log out	17
phone lock	
manual lock	17
unlock	18
phone settings	
call history	38
call timers	56
log recent calls	38
visual alerting	58
physical layout	
front face	10
product ID	
phone	66
provisioning server	15

R

recents	
adding a contact	39
call history	37
call log	37
clearing all	39
clearing all entries	39
deleting a call record	39
making a call	31
missed call	27
viewing call details	38
related documentation	68
resume	
call,	44
ring type	
audio settings	59
settings	59

S

search	
contacts	35
first name	35
searching	
corporate database	31
enterprise directory	35
local	35
searching for content	71
secondary provisioning server address	67
security	
WEP, WPA/WPA2 PSK, 802.1x EAP	20
send all calls	
do not disturb	45

server	
Avaya Aura	67
Open SIP	67
setting network mode	
Ethernet	18
Wi-Fi	18
settings	
AGC	60
audio settings	59 , 60
call history	38
call timers	56
date format	61
display settings	61
language	61
log recent calls	38
ring type	59
time format	62
time zone	62
visual alerting	58
shared control mode	53
sharing content	71
sidetone	
ambiance noise	60
sort documents	71
speed dialing	
contacts	57
removing contact	57
replacing contact	57
support	73
supported features	13

T

time zone	
display settings	62
settings	62
tooggling	
calls	30
hold	30
transferring call	
incoming call	28
outgoing call	28

U

unattended call transfer	52
unlockPIN	
password	18
update	
phone	64
user data	
backing up	63
backup	63
restore	63
restoring	63

V

videos	72
viewing	
product ID	66
voice mail	
beacon LED	55
voice mail user ID	55
voicemail	
voice mail	54
voice message	54

W

watchlist	71
-----------	--------------------