



Using a Voicemail Pro Intuity Mode Mailbox

Notices

© 2026 Avaya LLC. All Rights Reserved.

You may, at your own risk, assemble a MyDocs collection solely for your own internal business purposes, which constitutes a modification to the original published version of the publications. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of publications. You agree to defend, indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, your modifications, additions or deletions to the publications.

A single topic or a collection of topics may come from multiple Avaya publications. All of the content in your collection is subject to the legal notices and disclaimers in the publications from which you assembled the collection. For information on licenses and license types, trademarks, and regulatory statements, see the original publications from which you copied the topics in your collection.

Except where expressly stated by Avaya otherwise, no use should be made of materials provided by Avaya on this site. All content on this site and the publications provided by Avaya including the selection, arrangement and design of the content is owned by Avaya and/or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. Avaya owns all right, title and interest to any modifications, additions or deletions to the content in the Avaya publications.

공지 사항

Avaya은(는) 본 문서의 발행 시점에서 문서의 내용에 완전성과 정확성을 기하기 위해 합리적 노력을 기울였으며, 오류에 대해서는 일체 책임을 지지 않습니다. Avaya은(는) 일체의 개인이나 조직에게 통보할 의무 없이 본 문서의 정보에 대해 변경 및 수정할 권리를 보유합니다.

문서 책임 면제 조항

"문서"는 다양한 매체로 발행한 정보를 의미하며, 여기에는 일반적으로 제품 사용자가 사용할 수 있도록 한 제품 정보, 구독 또는 서비스 설명, 작동 지침 및 성능 사양이 포함되어 있을 수 있습니다. 마케팅 자료는 문서에 포함되지 않습니다. Avaya은(는) 그러한 수정, 추가 또는 삭제에 Avaya에 의해 또는 대신하여 명시적으로 수행된 경우를 제외하고, 문서의 원 발행본에 대한 수정, 추가 또는 삭제에 대해 일체 책임을 지지 않습니다. 최종 사용자는 최종 사용자에게 의한 이 문서의 수정, 추가 또는 삭제에 의해 발생하는 또는 이와 연관되는 모든 청구, 소송, 요구 및 판결에 대해 Avaya, Avaya의 대리인, 고용인 및 직원에게 법적 책임을 지우지 않고 손해를 입히지 않을 것에 동의합니다.

링크 책임 면제 조항

Avaya은(는) 이 사이트 또는 Avaya에서 제공하는 문서 내에서 참조용으로 링크된 웹 사이트의 내용 또는 신뢰성에 대해 일체 책임을 지지 않습니다. Avaya은(는) 이들 사이트에 제공된 모든 정보, 주장 또는 내용의 정확성에 대해 일체 책임을 지지 않으며 해당 웹 사이트에서 설명하거나 제공하는 제품, 서비스 및 정보를 보증하지 않습니다. Avaya은(는) 이들 링크가 항상 작동하게 될 것임을 보증하지 않으며 링크된 페이지의 가용성에 대하여 일체 관여하지 않습니다.

보증

Avaya에서는 Avaya 하드웨어 및 소프트웨어에 대한 제한적 보증을 제공합니다. 제한적 보증 조건에 대해서는 Avaya와의 계약을 참조하십시오. 또한 보증 기간 중 Avaya 고객과 타사에게 "보증 및 제품 수명 주기" 링크의 Avaya 지원 웹 사이트 <https://support.avaya.com/helpcenter/getGenericDetails?detailId=C20091120112456651010> 또는 Avaya에서 지정한 후속 사이트를 통해 Avaya의 표준 보증 언어와 이 제품의 지원과 관련된 정보가 제공됩니다. 미국 및 캐나다 이외 지역의 공인 Avaya 채널 파트너로부터 제품을 구입한 경우 Avaya이(가) 아닌 해당 Avaya 채널 파트너에 의해 보증이 제공됩니다.

"호스팅 서비스"란 Avaya 또는 공인 Avaya 채널 파트너(해당하는 경우)로부터 구입한 것으로, 호스팅 SAS 또는 해당하는 호스팅 서비스에 관한 기타 서비스 설명서에 자세히 설명되어 있는 Avaya 호스팅 서비스 구독을 의미합니다. 호스팅 서비스 구독을 구입한 경우 전술한 제한적 보증이 적용되지 않을 수 있으며, 해당하는 호스팅 서비스에 관한 기타 서비스 설명서에 자세히 설명된 대로 호스팅 서비스와 연관된 지원 서비스를 받을 수 있습니다. 자세한 내용은 Avaya 또는 Avaya 채널 파트너(해당하는 경우)에 문의하십시오.

호스팅 서비스

다음은 Avaya 또는 Avaya 채널 파트너(해당하는 경우)로부터 호스팅 서비스 구독을 구입한 경우에 적용됩니다. 호스팅 서비스에 대한 이용 약관은 Avaya 웹 사이트(<https://support.avaya.com/licenseinfo>)의 "호스팅 서비스에 대한 Avaya 이용 약관" 링크 또는 Avaya에서 지정한 후속 사이트에서 확인할 수 있으며, 호스팅 서비스에 액세스하거나 호스팅 서비스를 사용하는 모든 사용자에게 적용됩니다. 호스팅 서비스에 액세스하거나 이를 사용하거나 다른 사람이 액세스하도록 허용할 경우 귀하와 귀하를 대신해 작업을 수행하는 사람 및 귀하가 속한 조직(이하 "귀하" 또는 "최종 사용자")은 이용 약관에 동의하게 됩니다. 회사 또는 기타 법인을 대신해 이용 약관에 동의하는 경우 이는 귀하에게 해당 주제에서 이러한 이용 약관에 구속되도록 할 권한이 있음을 진술하는 것입니다. 상기 권한이 없거나 이러한 이용 약관에 동의하지 않으려면 호스팅 서비스에 액세스하거나 사용해서는 안 되며, 누구에게도 호스팅 서비스에 액세스하거나 사용할 권한을 부여해서는 안 됩니다.

라이선스

글로벌 소프트웨어 라이선스 약관("소프트웨어 라이선스 약관")은 다음 웹 사이트 <https://www.avaya.com/en/legal-license-terms/> 또는 Avaya에서 지정한 후속 사이트에서 사용할 수 있습니다. 본 소프트웨어 라이선스 약관은 소프트웨어 및/또는 문서를 설치, 다운로드 및/또는 사용하는 모든 사람에게 적용됩니다. 소프트웨어를 설치, 다운로드 또는 사용하거나 다른 사람에게 그렇게 하도록 권한을 부여함으로써 최종 사용자는 소프트웨어 라이선스 약관이 해당 사용자와 Avaya 간에 구속력 있는 계약을 생성한다는 데 동의합니다. 최종 사용자가 회사 또는 기타 법인을 대신하여 본 소프트웨어 라이선스 약관에 동의하

는 경우, 최종 사용자는 해당 법인이 본 소프트웨어 라이선스 약관에 구속되도록 할 권한이 있음을 진술합니다.

저작권

달리 명시적으로 언급한 경우를 제외하고 이 사이트의 자료, Avaya에서 제공하는 문서, 소프트웨어, 호스팅 서비스 또는 하드웨어의 사용은 금지됩니다. 콘텐츠의 선택, 배열 및 디자인을 포함하여 이 사이트의 모든 콘텐츠, Avaya에서 제공하는 문서, 호스팅 서비스 및 제품은 Avaya 또는 사용 허가자가 소유하며 데이터베이스 보호와 관련된 독자적인 권리를 포함한 저작권 및 기타 지적 재산권법에 의해 보호됩니다. Avaya에서 명시적으로 승인하지 않는 한, 코드 및 소프트웨어를 포함한 일부 또는 전체 콘텐츠는 어떤 방식으로든 수정, 복사, 복제, 재발행, 업로드, 게시, 전송 또는 배포할 수 없습니다. Avaya의 서면 동의 없이 무단으로 복제, 전송, 보급, 저장 및/또는 사용하는 것은 해당 법규에 위거하여 민형사상의 범죄 행위가 될 수 있습니다.

가상화

다음은 제품이 가상 기계에 배포된 경우 적용됩니다. 제품마다 고유한 주문 코드와 라이선스 유형이 있습니다. 따라서 별도로 명시하지 않는 한, 제품의 각 인스턴스를 별도로 주문하고 라이선스를 획득해야 합니다. 예를 들어 최종 사용자 고객 또는 Avaya 채널 파트너가 동일 유형 제품의 두 인스턴스를 설치하려면 해당 유형의 제품을 두 개 주문해야 합니다.

제3자 구성 요소

다음은 H.264(AVC) 코덱이 제품과 함께 배포된 경우에만 적용됩니다. 소비자의 개인적인 사용 또는 (i) AVC 표준을 준수하는 비디오 인코딩("AVC 비디오") 및/또는 (ii) 개인적인 활동에 참여하거나 AVC 비디오를 제공할 권한이 있는 비디오 공급자로부터 구입한 소비자가 인코딩한 AVC 비디오 디코딩에 대해 대가를 받지 않는 기타 사용의 경우 본 제품은 AVC 특허 포트폴리오 라이선스에 따라 사용이 허가됩니다. 그 외에 허여되거나 다른 용도가 함축된 라이선스는 없습니다. 자세한 내용은 MPEG LA, L.L.C에서 확인할 수 있습니다. [HTTP://WWW.MPEGLA.COM](http://www.MPEGLA.com)을 참조하십시오.

서비스 제공자

코덱과 관련하여 Avaya 채널 파트너가 H.264 코덱 또는 H.265 코덱을 사용하거나 내장한 제품을 호스팅하는 경우 Avaya 채널 파트너는 Avaya 채널 파트너가 모든 관련 요금 및/또는 로열티에 대해 책임을 진다는 사실을 인정하고 이에 동의합니다. H.264(AVC) 코덱은 소비자의 개인적인 사용 또는 (i) AVC 표준을 준수하는 비디오 인코딩("AVC 비디오") 및/또는 (ii) 개인적인 활동에 참여하거나 AVC 비디오를 제공할 권한이 있는 비디오 공급자로부터 구입한 소비자가 인코딩한 AVC 비디오 디코딩에 대해 대가를 받지 않는 기타 사용의 경우 본 제품은 AVC 특허 포트폴리오 라이선스에 따라 사용이 허가됩니다. 그 외에 허여되거나 다른 용도가 함축된 라이선스는 없습니다. H.264(AVC) 및 H.265(HEVC) 코덱에 대한 자세한 정보는 MPEG LA, L.L.C에서 얻을 수 있습니다. [HTTP://WWW.MPEGLA.COM](http://www.MPEGLA.COM)을 참조하십시오.

법률 준수

귀하는 Avaya 제품이 사용되는 국가 또는 지역에서 통화 기록, 데이터 개인 정보, 지적 재산권, 영업 비밀, 사기 및 음 악 공연권과 관련된 법률 및 규정을 포함하여(이에 국한되지 않음) 적용 법률 및 규정을 준수하는 것은 귀하의 책임임을 인정하고 동의합니다.

시스템 불법 이용 방지

"시스템 불법 이용"은 회사 직원이나 대리인, 하청 계약자 또는 용역 업체 등에 속하지 않은 허가받지 않은 집단이 사용자의 통신 시스템을 무단으로 사용하는 경우입니다. 시스템과 관련된 시스템 불법 이용 위험이 있을 수 있으며 만일 시스템 불법 이용이 발생하는 경우, 통신 서비스에 상당한 추가 요금이 부과될 수 있습니다.

Avaya의 시스템 불법 이용 대처

귀하가 시스템 불법 이용의 피해를 받고 있다고 의심되고 기술 지원이나 지원이 필요한 경우 Avaya 영업 담당자에게 문의하십시오.

보안 취약점

Avaya의 보안 지원 정책에 대한 정보는 <https://support.avaya.com/security>의 보안 정책 및 지원 섹션에서 확인할 수 있습니다.

의심스러운 Avaya 제품 보안 취약점은 Avaya 제품 보안 지원 플로우(<https://support.avaya.com/css/P8/documents/100161515>)에 따라 처리됩니다.

상표

이 사이트에 표시된 상표, 로고 및 서비스 마크("상표"), Avaya에서 제공하는 문서, 호스팅 서비스 및 제품은 Avaya, 자회사, 라이선스 제공자, 공급업체 또는 기타 타사의 등록 또는 미등록 상표입니다. Avaya

또는 해당 상표를 소유한 타사로부터의 사전 서면 동의 없이는 사용자가 해당 상표를 사용할 수 없습니다. 본 사이트, 문서, 호스팅 서비스 및 제품에 포함되지 않은 것은 Avaya 또는 해당 타사의 서면 동의 없이는 해당 상표에 대한 모든 라이선스나 권리를 신뢰보호 원칙에 의거 암시적으로 허여하지 않은 것으로 간주합니다.

Avaya은(는) Avaya LLC.의 상표입니다.

Avaya이(가) 아닌 모든 상표는 해당 소유자의 자산입니다.

Linux[®]는 미국 및 기타 국가에서 Linus Torvalds의 등록 상표입니다.

문서 다운로드

최신 버전의 문서는 Avaya 지원 웹 사이트(<https://support.avaya.com>) 또는 Avaya에서 지정한 후속 사이트에서 확인할 수 있습니다.

Avaya 지원 센터 문의

제품 또는 클라우드 서비스 관련 공지 및 기사를 보거나 Avaya 제품 또는 클라우드 서비스와 관련된 문제를 보고하려면 Avaya 지원 센터 웹 사이트(<https://support.avaya.com>)를 참조하십시오. 지원 전화번호와 연락처 주소 목록을 보려면 Avaya 지원 센터 웹 사이트(<https://support.avaya.com>) 또는 Avaya에서 지정한 후속 사이트로 이동하여 페이지 하단으로 스크롤한 후 Avaya 지원 연락처를 선택하십시오.

Contents

Chapter 1: Introduction	6
Which Voicemail Do I Have?.....	6
Mailbox Limits and Automatic Message Deletion.....	7
Mailbox Options.....	7
Chapter 2: Logging Into Your Mailbox	10
First-Time Login.....	10
Logging In.....	11
Logging In Remotely.....	12
Logging into Visual Voice.....	12
Chapter 3: Listening to Messages	14
Listening to Messages.....	15
Calling the Message Sender.....	15
Replying to a Voice Message.....	16
Forwarding a Message.....	16
Sending a New Message.....	17
Scanning Messages.....	18
Chapter 4: Other Options	20
Recording a Message.....	20
Transferring a Call to a Mailbox.....	21
Chapter 5: Caller Options	22
Skipping the Mailbox Greeting.....	22
Breakout Options.....	22
Post-Message Options.....	23
Chapter 6: Mailing Lists	24
Creating a Mailing List.....	24
Reviewing a List.....	25
Changing the Status of a List.....	26
Adding Members to a List.....	27
Removing Members from a List.....	27
Deleting a List.....	28
Using a Mailing List.....	28
Forwarding to a List.....	29
Chapter 7: Greetings	30
Recording a Greeting.....	31
Administering Greetings.....	32
Assigning a Greeting to a Call Type.....	32
Unassigning a Call Type.....	33
Activating a Greeting.....	34
Deactivating a Greeting.....	35

Scanning Greetings.....	36
Listening to a Greeting.....	36
Changing a Greeting.....	37
Deleting a Greeting.....	38
Creating a Temporary Greeting.....	38
Chapter 8: Voicemail Notification.....	40
Turning Ringback On or Off.....	40
Outcalling.....	40
Configuring Your Outcalling Destinations.....	42
Turning Outcalling On or Off.....	42
Changing Your Destination Telephone Numbers.....	43
Changing the Timeout Setting.....	44
Creating an Escalation List.....	44
Selecting When to Receive Outcalling.....	46
Specifying Your Own Time Schedule.....	46
Answering Outcalling Calls.....	47
Chapter 9: Mailbox Administration.....	49
Changing Your Password.....	49
Recording Your Name.....	50
Addressing a Message Before You Record.....	50
Preventing Further Calls and Messages.....	51
Setting the Order of Message Playback.....	51
Chapter 10: Fax Messages.....	53
Forwarding a Fax Messages.....	53
Setting a Personal Fax Number.....	54
Deleting Your Personal Fax Number.....	54
Chapter 11: Visual Voice.....	56
Logging into Visual Voice.....	56
Visual Voice Controls.....	57
12장: 추가 도움말 및 문서.....	58
암호 분실.....	58
도움말 받기.....	58
추가 문서.....	59

Chapter 1: Introduction

This document covers mailbox operation on IP Office system using a Voicemail Pro server running in Intuity emulation mailbox mode. If you are not sure which system you have and the mode it is operating in, see [Which Voicemail Do I Have?](#) on page 6.

- Intuity is a set of spoken voicemail mailbox prompts supported by many Avaya voicemail systems. Your system supports a sub-set of the full Intuity feature set.

Related links

[Which Voicemail Do I Have?](#) on page 6

[Mailbox Limits and Automatic Message Deletion](#) on page 7

[Mailbox Options](#) on page 7

Which Voicemail Do I Have?

The operation of voicemail is highly customizable. So it is important that you use the correct mailbox guide:

How Do I Determine Which Guide to Use?

Your system administrator can tell you what type of voicemail your Avaya IP Office system is using. However, the following process may help you to determine it for yourself:

1. On your phone, dial *17 to access voicemail.
2. After the initial greeting, if the voicemail asks “Please enter extension and pound key”, then the voicemail system is running in Intuity mode. Otherwise, go to step 3.
 - a. Press 7. If the system responds with a set of scan options, your voicemail server is Voicemail Pro.
 - b. If the system doesn't respond, your voicemail server is Embedded Voicemail.
3. If otherwise, your voicemail system is running in IP Office mode. Press *05.
 - a. If the system responds with a set of options, your voicemail server is Embedded Voicemail.
 - b. If the system doesn't respond, your voicemail server is Voicemail Pro.

Depending on the above, the following mailbox user guides are available:

- [Using IP Office Embedded Voicemail IP Office Mode](#)

- [Using IP Office Embedded Voicemail Intuity Mode](#)
- [Using a Voicemail Pro Intuity Mode Mailbox](#)
- [Using a Voicemail Pro IP Office Mode Mailbox](#)

Related links

[Introduction](#) on page 6

Mailbox Limits and Automatic Message Deletion

Your mailbox is limited to 60 minutes of messages and recordings. Once that limit is reached, additional callers are told that they cannot leave a message and your system administrator may receive an alarm.

In normal use, the system automatically deletes a message 30 days after you have played any part of it.

Related links

[Introduction](#) on page 6

Mailbox Options

This table provides a summary of the mailbox options available to you when you login to a mailbox.

Activity Menu	Menu	Sub-Menu
Record: 1	<ul style="list-style-type: none"> • Record Message: 1 • Start/Stop Recording: 1 • Rewind: 2 • Replay: 5 • Advance: 6 • Playback: 23 • Delete: *3 • Approve: # (see sub-menu) 	<ul style="list-style-type: none"> • Enter address and press # • Cancel address: *3 • Name/Number addressing: *2 • Use mailing list: *5 • Finish addressing: #

Table continues...

Activity Menu	Menu	Sub-Menu
Get Messages: 2	<ul style="list-style-type: none"> • Skip Header: 0 • Reply/Forward: 1 (<i>see sub-menu</i>) • Restart: 2 • Skip to Previous: *2 • Pause/Resume: 3 • Replay Header: 23 • Back: 5 • Restart: *5 • Advance: 6 • Skip Category: *# • Play Next: # • Save in Current Category: **4 • Erase and Play Next: *3 • Undelete: **8 • Print Fax: *1 	<ul style="list-style-type: none"> • Call Sender: 0 • Reply without original: 16 • Reply with original: 19 • Forward with comment at start: 2 • Forward with comment at end: 3 • Send Another Message: 4
Personal Greetings: 3	<ul style="list-style-type: none"> • Listen to Greeting: 0 (<i>see sub-menu</i>) • Create/Change Greeting: 1 (<i>see sub-menu</i>) • Scan All: 2 	<ul style="list-style-type: none"> • Replay: 0 • Review Status: 2 • Record: 1 • Delete: *3 • Save: #
	<ul style="list-style-type: none"> • Activate Greeting: 3 (<i>see sub-menu</i>) • Administer Call Types: 4 (<i>see sub-menu</i>) 	<ul style="list-style-type: none"> • All Call: 1 • Internal Calls: 2 • External Calls: 3 • Engaged Calls: 4 • No Reply Calls: 5 • Out of Hours Calls: 6 • Out of Service Calls: 7 • Default Greeting Calls: 8 • Temporary Greeting: 9

Table continues...


Activity Menu	Menu	Sub-Menu
Personal Options: 5	<ul style="list-style-type: none"> • Mailing Lists: 1 (<i>see sub-menu</i>) • Fax Options: 3 • Password: 4 • Record Name: 5 • Address After Record: 6 • Accept Call Answer: 7 • Media Preferences: 8 	<ul style="list-style-type: none"> • Create List: 1 • Scan Lists: 2 • Review and Modify: 3 • Restart: *5
Outcalling: 6	<ul style="list-style-type: none"> • Configure Outcalling: 1 • Change Times: 2 • Change Numbers: 3 • Turn Off: 6 • Turn On: 9 	
Scan Messages: 7	<ul style="list-style-type: none"> • Headers and Messages: 1 • Headers Only: 2 • Messages Only: 3 	
<ul style="list-style-type: none"> • Help: *4 • Call an extension number: *8 • Login to another mailbox: **7 • Exit voicemail: **9 		

Related links

[Introduction](#) on page 6

Chapter 2: Logging Into Your Mailbox

The way in which you log in to your Intuity mailbox is the same whether or not it is the first time you have logged in. The prompts that you hear are different.

- When you log in to your mailbox for the first time, you may be asked to set a mailbox password and to record your name.
- For subsequent times, you need only enter your mailbox number and password.
- Many Avaya telephones have a  key or menus for gaining access to voicemail mailboxes.
- You can also use the one-X Portal for IP Office application. It can display when you have voicemail messages.
- Occasionally, you may want to log in to your mailbox from a telephone that is not on the telephone network of your organization. For more information, see [Logging In Remotely](#) on page 12.

Related links

[First-Time Login](#) on page 10

[Logging In](#) on page 11

[Logging In Remotely](#) on page 12

[Logging into Visual Voice](#) on page 12

First-Time Login

About this task

The first time you call your mailbox you are prompted to record your name and change the mailbox password. The name that you record is used in various system announcements and in the voicemail system directory search.

Similarly, your system administrator can tell you if your mailbox already has a password set. Typically, a password is not set until the first time you log in.

Procedure

1. On any extension, dial ***17**.
2. If you are dialing from your own extension, press **#**. Otherwise, enter your extension number and press **#**.
3. Enter your password and press **#**. If a password has not been set yet, just press **#**.

4. You are asked to enter a new password. Enter and confirm the password you want to use.
 - You must enter at least 6-digits. The system allows up to 15-digits.
 - You cannot use your extension number, repeated digits or consecutive numbers.
 - You cannot use common key pad patterns such as 1397.
 - Your system administrator can change the minimum requirements and will inform you if they are different.
5. Record your name when you are prompted.
 - a. Press **1** and at the tone, speak your name.
 - b. Press **1** again. Your recording is played back.
 - c. Either press **#** to accept the recording or **1** to record again.
6. After you log in, the voice prompts tell you what to do. For a summary, see [Mailbox Options](#) on page 7.

Related links

[Logging Into Your Mailbox](#) on page 10

Logging In

About this task

If you have already logged in once and recorded your name and set a password, you need only enter your mailbox number and the password.

Procedure

1. On any extension, dial ***17**.
2. If you are dialing from your own extension, press **#**. Otherwise, enter your extension number and press **#**.
3. Enter your password and press **#**.
4. After you log in, the voice prompts tell you what to do. For a summary, see [Mailbox Options](#) on page 7.

Related links

[Logging Into Your Mailbox](#) on page 10

Logging In Remotely

About this task

You can log in to mailboxes from a telephone that is not on your telephone system. Your system administrator may configure a special number for that. However, if that is not the case, you can use the method below to log in remotely.

Procedure

1. Call your company. If necessary, ask to be connected to a number that will go to voicemail. For example; your own extension assuming you have it set to send unanswered calls to voicemail.
2. Wait for the voicemail system to respond and ask you to leave a message.
3. Press **#**. Voicemail announces the actions that you can perform.
4. Dial ***7**.
 - If you have already logged into a mailbox, you can access this option to login to a different mailbox by pressing ****7**.
5. Enter your extension number and press **#**.
6. Enter your password and press **#**.
7. After you log in, the voice prompts tell you what to do. For a summary, see [Mailbox Options](#) on page 7.


Related links

[Logging Into Your Mailbox](#) on page 10

Logging into Visual Voice


About this task

Visual voice is a set of Avaya phone menus that you can use to access your mailbox and the mailbox settings.

By default, the  button on Avaya phones accesses the visual voice menus for the phone user's mailbox.

- Your system administrator can also configure the visual voice menus for your phone to provide access to messages in other users and groups mailboxes.

Procedure

1. Either:
 - a. Press the  button on your Avaya phone.
 - b. Press **Features**. Scroll down to **Visual Voice** and press **Select**.

- c. Press the optional **Visual Voice** button that has been programmed on your phone.
2. The visual voice options should appear on the phone's screen. See [Visual Voice Controls](#) on page 57.

Related links

[Logging Into Your Mailbox](#) on page 10

[Visual Voice](#) on page 56

Chapter 3: Listening to Messages

When you have successfully logged in to your mailbox (see [Logging In](#) on page 11), you will hear an announcement telling you about the messages that you have. For example, you hear the number of voice messages.

You can listen to your messages or record a new message and send it.

If any of your messages are emails, you can also reply. If any of your messages are fax messages, you can specify a personal fax number so that you can forward or print them. You will only receive email and/or fax messages configured by your system administrator.

Playback Order - By Message Type

By default, voicemail plays messages to you in the following order:

1. **Voice messages**
2. **Fax messages**
3. **Email messages**

Each message starts with a header, which contains details about who the message is from (if known) and when it was left. For fax messages, the header includes the number of pages. You can change the order if you prefer to hear the types of message in a different order, for example email messages first. For more information, see [Setting the Order in which Messages are Played](#).

Playback Order - By Message Status

Message of all types are grouped in to the following categories. Priority messages are played first, followed by new messages and then old messages.

1. **Priority:** When a caller leaves a message, they can mark it as a priority message.
2. **New:** A message that has not been listened to.
3. **Old:** After you have listened to a new message it becomes an old message. Unless you delete them sooner, messages are automatically deleted after 30 days. See [Mailbox Limits and Automatic Message Deletion](#) on page 7.(720 hours). Check with your system administrator to find out how long messages are stored before they are automatically deleted.

Related links

- [Listening to Messages](#) on page 15
- [Calling the Message Sender](#) on page 15
- [Replying to a Voice Message](#) on page 16
- [Forwarding a Message](#) on page 16
- [Sending a New Message](#) on page 17
- [Scanning Messages](#) on page 18

Listening to Messages

About this task

When you receive messages, you can skip the header and listen to the message. While listening to your messages, you can listen to all or just part of the message again.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. The number of new messages is announced. The announcement tells you how many of those messages are priority messages.
3. Press **2** to receive your messages. The header of the first message is played.
 - To skip the message header and listen to the message, press **0**.
4. As you listen to each message, you can use the following controls to listen to all or part of the message again.
 - **To restart:** Press **2**.
 - **To replay header:** Press **23**.
 - **To pause/resume:** Press **3**.
 - **To rewind 5 seconds:** Press **5**.
 - **To restart:** Press ***5**.
 - **To advance 5 seconds:** Press **6**.
5. When you have listened to the message, you have the following options:
 - To reply to the message, press **1** . See [Replying to a Voice Message](#) on page 16.
 - To forward a fax message, press ***1** . See [Forwarding a Fax Messages](#) on page 53.
 - To delete the message and continue to the next message, press ***3**.
 - To play the next message, press **#** .

Related links

[Listening to Messages](#) on page 14

Calling the Message Sender

About this task

If the message you are listening to was from another extension, you can call the sender back.

Procedure

1. While listening to the message, press **1**.

2. To make a call to the sender, press **0**. You are logged out of your mailbox.

Related links

[Listening to Messages](#) on page 14

Replying to a Voice Message

About this task

When you receive a voice message, you can send a reply message to the sender. You can choose to reply with or without the original message attached.

Procedure

1. While listening to the message, press **1**.
2. To reply to the message, press **1** again.
3. Select how to reply:
 - To reply without the original message attached, press **6**.
 - To reply with the original message attached, press **9**.
4. After the tone, record your reply.
5. When you have finished, press **#**.

Related links

[Listening to Messages](#) on page 14

Forwarding a Message

About this task

You can forward a voice message to another mailbox or mailboxes. You can add your own comment to the message to be played before the original message.

- An email message can only be forwarded to one mailbox at a time.
- You cannot forward a voice message if it has been marked as private by the sender.
- The comments that are recorded are played followed by the forwarded message.
- If you regularly forward messages to the same group of people, you can create and use a mailing list. See [Mailing Lists](#) on page 24.
- You can configure your mailbox to set address before sending or after. See [Addressing a Message Before You Record](#) on page 50.

Procedure

1. While listening to the message, press **1**.
2. Press **2** to forward the message with a comment.
3. Record your comment and press **#** to finish recording.
4. Voicemail prompts you to enter the forwarding addresses:
 - a. To switch between entering addresses by extension number or by matching user names, press ***2**.
 - b. Enter a mailbox number (or dial the required name) and then press **#**.
 - c. To select and add a mailing list (see [Mailing Lists](#) on page 24), press ***5**. Press **#** to select one of your own lists. Otherwise, enter the mailbox number of the list owner and press **#**. Enter the number of the list and press **#**.
 - d. Repeat until you have entered all the mailboxes to which you want to forward the message.
 - e. To delete the last number you entered, press ***3**.
 - f. Press **#** to finish addressing.
5. Press **#** to send the forwarded message.

Related links

[Listening to Messages](#) on page 14

Sending a New Message

About this task

You can send a new message to another mailbox or mailboxes.

- If you regularly forward messages to the same group of people, you can create and use a mailing list. See [Mailing Lists](#) on page 24.
- You can configure your mailbox to set address before sending or after. See [Addressing a Message Before You Record](#) on page 50.

Procedure

1. While listening to the message, press **1**.
2. Press **4**. You are prompted to record your new message. Record your comment and press **#** to finish recording.
3. Voicemail prompts you to enter the forwarding addresses:
 - a. To switch between entering addresses by extension number or by matching user names, press ***2**.
 - b. Enter a mailbox number (or dial the required name) and then press **#**.

- c. To select and add a mailing list (see [Mailing Lists](#) on page 24), press *5 . Press # to select one of your own lists. Otherwise, enter the mailbox number of the list owner and press #. Enter the number of the list and press #.
 - d. Repeat until you have entered all the mailboxes to which you want to forward the message.
 - e. To delete the last number you entered, press *3.
 - f. Press # to finish addressing.
4. If required, select one of the following options:
- **To mark the message as private:** Press 1. Private messages cannot be forwarded to users other than the original recipients.
 - **To mark the message as priority:** Press 2. Priority messages are played before new messages.
5. Press # to send copies of the message to other mailboxes.

Related links

[Listening to Messages](#) on page 14

Scanning Messages

About this task

You can scan through your messages and/or message headers without having to take any further action. The message header tells you when a message was received, who left it (if known) and the message length.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press 7 to select scan messages.
 - To scan the headers and messages, press 1.
 - To scan headers only, press 2.
 - To scan messages only, press 3.
3. While your message header or message is playing:
 - To rewind current message, press 2.
 - To pause/resume, press 3.
 - To exit scan messages, press *7.

4. When you are listening to a message, you can press **1** to respond or forward the message. You then have the options to:
 - To call the sender of the message, press **0**.
 - To leave a voice message in the caller's mailbox, press **1**.
 - To forward the message to another mailbox, press **2**.
 - To send a new message to another mailbox owner, press **4**.
5. After you have listened to all of your messages, you are returned to the activity menu.

Related links

[Listening to Messages](#) on page 14

Chapter 4: Other Options

This section covers other voicemail options and controls.

Related links

[Recording a Message](#) on page 20

[Transferring a Call to a Mailbox](#) on page 21

Recording a Message

About this task

You can record a message and send it to another mailbox or several mailboxes at the same time.

- Recordings must be at least 3 seconds long. The system will automatically delete any messages that are shorter.
- If you regularly forward messages to the same group of people, you can create and use a mailing list. See [Mailing Lists](#) on page 24.
- You can configure your mailbox to set address before sending or after. See [Addressing a Message Before You Record](#) on page 50.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To select recording, press **1**. After the tone, start recording your message:
 - Press **#** to end the recording or press **1** to edit the recording that has just been made.
 - **To stop/start recording:** Press **1**.
 - **To rewind the recording:** Press **2**.
 - **To play back the recording:** Press **23**.
 - **To delete the recording:** Press ***3**.
 - **To approve the recording:** Press **#**.
3. Voicemail prompts you to enter the forwarding addresses:
 - a. To switch between entering addresses by extension number or by matching user names, press ***2**.
 - b. Enter a mailbox number (or dial the required name) and then press **#**.


- c. To select and add a mailing list (see [Mailing Lists](#) on page 24), press *5 . Press # to select one of your own lists. Otherwise, enter the mailbox number of the list owner and press #. Enter the number of the list and press #.
 - d. Repeat until you have entered all the mailboxes to which you want to forward the message.
 - e. To delete the last number you entered, press *3.
 - f. Press # to finish addressing.
4. If required, select one of the following options:
 - **To mark the message as private:** Press 1. Private messages cannot be forwarded to users other than the original recipients.
 - **To mark the message as priority:** Press 2. Priority messages are played before new messages.
 5. Press # to send copies of the message to other mailboxes.

Related links


[Other Options](#) on page 20

Transferring a Call to a Mailbox

About this task

You can use the  button on your phone as the destination for call transfers. This allows you to transfer a caller directly to another user's or group's mailbox to leave a message.

Procedure

1. Press **Transfer**.
2. Press the  button.
3. Enter the extension number of the mailbox required.
4. Complete the transfer.

Related links

[Other Options](#) on page 20

Chapter 5: Caller Options

The voicemail service provides options to callers other than just leaving a message.

Related links

[Skipping the Mailbox Greeting](#) on page 22

[Breakout Options](#) on page 22

[Post-Message Options](#) on page 23

Skipping the Mailbox Greeting

About this task

You and other callers can skip the mailbox owners greeting when you are directed to leave a message.

Procedure

1. As soon as you hear the mailbox greeting, press **1**.
2. You hear a tone, after which you can record your message.

Related links

[Caller Options](#) on page 22

Breakout Options

Your system administrator can configure a number of breakout options. Whilst listening to your greeting, callers may be able to press **0**, **2** or **3** to be transferred to another extension. For example, press **0** to transfer to your company receptionist.

If your system administrator has configured any of these options, it is useful to include them in any greetings you record for your mailbox.

Related links

[Caller Options](#) on page 22

Post-Message Options

About this task

After having recorded a message to be left in a mailbox, rather than just hanging up, you can use the following options.

Procedure

1. Leave a message as normal.
2. Instead of hanging up, press **#**.
3. If required, select one of the following options:
 - **To mark the message as private:** Press **1**. Private messages cannot be forwarded to users other than the original recipients.
 - **To mark the message as priority:** Press **2**. Priority messages are played before new messages.
4. Press **#** to send copies of the message to other mailboxes.
5. Having sent the message, you can now use one of the following options:
 - To login to a mailbox, press ***7**. See [Logging In Remotely](#) on page 12.
 - To be transferred to an extension number, press ***8** and enter the extension number.
 - To end the call, hang up as normal.

Related links

[Caller Options](#) on page 22

Chapter 6: Mailing Lists

With mailing lists (also known as personal distribution lists) you can store sets of mailbox numbers so that you can send a voice message to several recipients at the same time. This is useful if you often send messages to the same people, for example the members of one or more departments or even the whole company.

Your mailbox can have up to 20 mailing lists associated with it. Each list can contain up to 360 mailbox numbers. Lists can be private or public.

- Private lists can be used only by you while public lists can be used by other mailbox users when they forward a message.
- If you create a public list, it cannot be modified by other users.
- When you address a message, you can select one of your own mailing lists or a public list from a different mailbox.

Once a list has been created, it can be used to send and forward messages using the telephone. The list can also be changed or deleted using the telephone.

Related links

[Creating a Mailing List](#) on page 24

[Reviewing a List](#) on page 25

[Changing the Status of a List](#) on page 26

[Adding Members to a List](#) on page 27

[Removing Members from a List](#) on page 27

[Deleting a List](#) on page 28

[Using a Mailing List](#) on page 28

[Forwarding to a List](#) on page 29

Creating a Mailing List

About this task

You can create up to 20 mailing lists for your mailbox. Each mailing list can contain up to 360 mailbox numbers. Once a list has been created, it can be used to send and forward messages using the telephone. The list can also be changed or deleted using the telephone.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.

2. Press **5** for personal options.
3. Press **1** for mailing list options.
4. Press **1** to create a new mailing list.
5. Enter a number to identify the list and then press **#**.
 - The list identifying number must be less than 6 digits long. If the number is too long or already in use, voicemail prompts you to enter a different number followed by **#**.
6. Mark the list as private or public:
 - To mark a list a private, press **1**. A private list can only be used by you.
 - To mark a list as public, press **2**. A public list can be used by other users.
7. When prompted, start adding mailboxes to the mailing list. To add a mailbox, enter the mailbox number and press **#**. For local mailboxes the name of mailbox user is confirmed. You can also select the following options while you add mailboxes:
 - Press ***2** to switch to selecting mailboxes by name.
 - Press ***5** to import the contents of another public mailbox list.
 - You are asked to enter the mailbox number of the list owner followed by **#** and then the list number followed by **#**.
 - If the mailbox or list is not valid or the list is private, you are returned to the option for creating a mailbox list in the usual way.
 - If the list exists and is public, its contents are imported as long as importing does not result in a list of more than 360 entries. Any duplicate entries are automatically removed.
8. Press **#** to finish.

Related links

[Mailing Lists](#) on page 24

Reviewing a List

About this task

When a mailing list has been created you can find out the list identification number and the members of the listing by scanning or reviewing your mailing lists.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **1** for mailing list options.

4. Press **2** to scan your mailing lists.
5. You hear the number of the lowest numbered list, the number of members it contains and whether it is private or public.
6. You can now use the following options:
 - To listen to the list details, press **0**.
 - To skip to the next list, press **#**.

Related links

[Mailing Lists](#) on page 24

Changing the Status of a List

About this task

The status of a mailing lists can be private or public. When a mailing list is public, anyone can use the list to send a message to all the members of the listing. A private mailing list can only be used by the person that owns the list.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **1** for mailing list options.
4. Press **3** to modify mailing lists.
5. When prompted to enter the list owner's number, press **#** for your lists.
6. Enter the list number and press **#**. Voicemail announces the list details.
7. Press **1** to add or change details of the mailing list. Voicemail announces the status of the mailing list.
8. To change the status of the list, press **9**. The new status of the mailing list is announced.
9. Press **#**.
10. Press **#** to finish.
11. Press ***#** to finish.

Related links

[Mailing Lists](#) on page 24

Adding Members to a List

About this task

When a mailing list has been created, new members can be added to the listing.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **1** for mailing list options.
4. Press **3** to modify mailing lists.
5. When prompted to enter the list owner's number, press **#** for your lists.
6. Enter the list number and press **#**. Voicemail announces the list details.
7. Press **1** to add or change details of the mailing list. Voicemail announces the status of the mailing list.
8. Press **6** to leave the list status unchanged.
9. Enter the new extension and press **#**.
10. Press **#** to finish.
11. Press ***#** to finish.

Related links

[Mailing Lists](#) on page 24

Removing Members from a List

About this task

When a mailing list has been created, members of the list can be removed from the listing.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **1** for mailing list options.
4. Press **3** to modify mailing lists.
5. When prompted to enter the list owner's number, press **#** for your lists.
6. Enter the list number and press **#**. Voicemail announces the list details.
7. The first mailbox name or number is announced:
 - Press ***3** to delete the mailing list member.

- Press **#** to hear the next member.
8. Press ***#** to finish.

Related links

[Mailing Lists](#) on page 24

Deleting a List

About this task

If a mailing list is no longer required, you can delete the list.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **1** for mailing list options.
4. Press **2** to scan your mailing lists.
5. Press **#** to skip the mailing lists not required.
6. Press ***3** when you hear the details of the mailing list that you want to delete.
7. Press ***7** to return to the activity menu.

Related links

[Mailing Lists](#) on page 24

Using a Mailing List

About this task

When you are logged in to your mailbox you can record a message and send it to all the mailboxes that are in a mailing list.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To select recording, press **1**. After the tone, start recording your message:
 - Press **#** to end the recording or press **1** to edit the recording that has just been made.
 - **To stop/start recording:** Press **1**.
 - **To rewind the recording:** Press **2**.
 - **To play back the recording:** Press **23**.

- **To delete the recording:** Press *3.
 - **To approve the recording:** Press #.
3. Voicemail prompts to enter the target extension. To select a mailing list, press *5:
 - a. For one of your own mailing lists, press #. For another user's public list, enter the user's extension number and press #.
 - b. Enter the list number and press #.
 4. Press #.
 5. If required, select one of the following options:
 - **To mark the message as private:** Press 1. Private messages cannot be forwarded to users other than the original recipients.
 - **To mark the message as priority:** Press 2. Priority messages are played before new messages.
 6. Press # to send copies of the message to other mailboxes.

Related links

[Mailing Lists](#) on page 24

Forwarding to a List

About this task

You can forward a message to the several mailboxes at the same time using a mailing list. Messages marked as private by the sender cannot be forwarded.

Procedure

1. While listening to the message, press 1.
2. Press 2 to forward the message with a comment.
3. Record your comment and press # to finish recording.
4. Voicemail prompts to enter the target extension. To select a mailing list, press *5:
 - a. For one of your own mailing lists, press #. For another user's public list, enter the user's extension number and press #.
 - b. Enter the list number and press #.
5. Press #.

Related links

[Mailing Lists](#) on page 24

Chapter 7: Greetings

By default, callers directed to your mailbox hear the default system greeting and your recorded name (see [Recording Your Name](#) on page 50). However, you can replace this with your own greetings.

Temporary Greeting

You can record a temporary greeting and specify how long in days it should be used. When you have a temporary greeting active, it overrides all your other mailbox greetings. See [Creating a Temporary Greeting](#) on page 38.

Personal Greetings

You can record a library of up to 9 personal greetings for a mailbox to which you have access. You can then select when a particular greeting is used. For example, you can assign different greetings to internal calls and external calls.

You can assign greetings to the call types listed below. If you have assigned greetings to several call types, voicemail uses the first one in the list that is applicable.

1. **Temporary Greeting**
2. **Out of Service** (*hunt group mailboxes only*)
3. **Out of Hours** (*hunt group mailboxes only*)
4. **All Calls**
5. **Internal Calls**
6. **External Calls**
7. **Number engaged calls**
8. **No reply calls**
9. **Default**

Breakout Options

Your system administrator can set up a maximum of three transfer options. If any transfer options have been created any caller who is directed to your voicemail can be given the option to be transferred to a different extension. The transfer options available are 0,2 and 3. Ideally a transfer option should be to an extension where a person is expected to answer. If a transfer results in the caller being diverted to a mailbox on the same system, they will be returned to your voicemail box.

If you are using the transfer options you should record a new greeting message to inform callers that if they press 0, 2 or 3 they will be transferred accordingly.

Related links

[Recording a Greeting](#) on page 31

- [Administering Greetings](#) on page 32
- [Activating a Greeting](#) on page 34
- [Deactivating a Greeting](#) on page 35
- [Scanning Greetings](#) on page 36
- [Listening to a Greeting](#) on page 36
- [Changing a Greeting](#) on page 37
- [Deleting a Greeting](#) on page 38
- [Creating a Temporary Greeting](#) on page 38

Recording a Greeting

About this task

You can record a library of up to 9 greetings that can be used as either a temporary greeting or as personal greetings applied to specific call types. The greetings are heard by callers when they are directed to your voicemail.

- A greeting must be longer than 3 seconds. The maximum length of a greeting is 120 seconds.
- If you record a personal greeting, you can choose to not assign the greeting until you need it used.
- If your system administrator has configured any breakout options (see [Breakout Options](#) on page 22), you should mention them in your greetings.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **1** to create, change or delete a greeting.
4. When prompted, select the greeting (1 to 9) you want to change. The system announces if the greeting is active (in use) for any call types.
5. At the tone, start speaking.
6. When finished, press **1**.
 - To play back the greeting you have just recorded, press **23**.
 - If you want to add to the recording, press **1**. Start speaking and press **1** when finished.
 - Press **#** to confirm the recording.

7. To save the recording, press #.

Next steps

The new greeting can be assigned to a call type by:

- Selecting the call type and then assigning the greeting. See [Assigning a Greeting to a Call Type](#) on page 32.
- Selecting the greeting and activating the greeting for a type of call. See [Activating a Greeting](#) on page 34.

Related links

[Greetings](#) on page 30

Administering Greetings

About this task

When you have recorded greetings, you can assign them to different call types. When you assign greetings to more than one call type, the greeting used for any call is decided using an order of priority.

Related links

[Greetings](#) on page 30

[Assigning a Greeting to a Call Type](#) on page 32

[Unassigning a Call Type](#) on page 33

Assigning a Greeting to a Call Type

About this task

The process allows you to select a call type and then assign one of your recorded greeting to that call type.

You can assign greetings to the call types listed below. If you have assigned greetings to several call types, voicemail uses the first one in the list that is applicable.

1. **Temporary Greeting**
2. **Out of Service** (*hunt group mailboxes only*)
3. **Out of Hours** (*hunt group mailboxes only*)
4. **All Calls**
5. **Internal Calls**
6. **External Calls**
7. **Number engaged calls**
8. **No reply calls**
9. **Default**

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **4** to administer call types.
4. Press **1** to activate a call type. You hear a message to confirm the call types possible.
5. Select the required call type:
 - **1** = All calls greeting
 - **2** = Internal calls greeting
 - **3** = External calls greeting
 - **4** = Engaged calls greeting
 - **5** = No reply greeting
 - **6** = Out of hours greeting
 - **7** = Out of service greeting
 - **8** = Default greeting
 - **9** = Temporary greeting
6. Enter the personal greeting number to assign to the call type selected.
7. Press **#**.

Related links

[Administering Greetings](#) on page 32

Unassigning a Call Type

About this task

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **0** to listen to the greetings.

4. When prompted, enter the number of the greeting to listen to. The greeting number and status is played.
5. Press *8 to unassociate the greeting. The greeting is not deleted but in no longer associated with any call type.
6. Press #.

Related links

[Administering Greetings](#) on page 32

Activating a Greeting

About this task

When you have recorded greetings (see [Recording a Greeting](#) on page 31), you can select the greeting and then assign it to a call type.

When you assign a personal greeting for more than one call type, the greeting used for any call is decided using an order of priority.

1. **Temporary Greeting**
2. **Out of Service** (*hunt group mailboxes only*)
3. **Out of Hours** (*hunt group mailboxes only*)
4. **All Calls**
5. **Internal Calls**
6. **External Calls**
7. **Number engaged calls**
8. **No reply calls**
9. **Default**

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, "*For internal calls greeting 1 active*".
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **3** to activate a call type. You hear a message to confirm the call types that are currently active
4. Enter the number of the personal greeting that you want used.

5. Enter the number of the call type to which the greeting should be assigned:

- 1 = All calls greeting
- 2 = Internal calls greeting
- 3 = External calls greeting
- 4 = Engaged calls greeting
- 5 = No reply greeting
- 6 = Out of hours greeting
- 7 = Out of service greeting
- 8 = Default greeting
- 9 = Temporary greeting

6. Press #.

Related links

[Greetings](#) on page 30

Deactivating a Greeting

About this task

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **4** to administer call types.
4. Press **2** to deactivate a call type. You hear a message to confirm the call types that are currently active
5. Select the required call type.
6. Press **#**.

Related links

[Greetings](#) on page 30

Scanning Greetings

About this task

You can scan through your current personal greetings to check which greetings are active and which call types they are assigned to. You can listen to each greeting if required.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **2** to scan greetings.
 - The status of the first greeting and its call assignment, if any, is played.
 - Press **0** to listen to the greeting.
 - Press **#** to skip to the next greeting.

Related links

[Greetings](#) on page 30

Listening to a Greeting

About this task

At any time you can check, and change, any of your existing personal greeting messages.

To listen to your greeting messages:

1. Log in to your mailbox.
2. Press **3** for personal greetings. If you have selected any call types, you hear an announcement that lists the call types and the greeting assigned to that call type. For example, you would hear *"For internal calls greeting 1 active"*.
3. Press **0** to listen to a greeting.
4. When you are prompted, enter the number of the greeting to listen to (1 to 9). The greeting number and status is played.
5. Press **0** to listen to the greeting.
6. Press **#** to return to the main greetings menu.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.

2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **0** to listen to greetings.
4. When prompted, enter the number of the greeting.
5. Press **0** to listen to the greeting.
6. Press **#**.

Related links

[Greetings](#) on page 30

Changing a Greeting

About this task

You can change the recording used for an existing greeting.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **1** to create, change or delete a greeting.
4. When prompted, select the greeting (1 to 9) you want to change. The system announces if the greeting is active (in use) for any call types.
5. At the tone, start speaking.
6. When finished, press **1**.
 - To play back the greeting you have just recorded, press **23**.
 - If you want to add to the recording, press **1**. Start speaking and press **1** when finished.
 - Press **#** to confirm the recording.
7. To save the recording, press **#**.
8. Press **#**.

Related links

[Greetings](#) on page 30

Deleting a Greeting

About this task

You can delete a greeting message any time. If you delete a greeting that is assigned to a call type, the system greeting is played.

When you are scanning your greetings, you can also delete any unwanted greetings by pressing *3 when prompted. For more information, see [Scanning Messages](#) on page 18.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **1** to create, change or delete a greeting.
4. When prompted, select the greeting (1 to 9) you want to change. The system announces if the greeting is active (in use) for any call types.
5. Press ***3**.

Related links

[Greetings](#) on page 30

Creating a Temporary Greeting

About this task

When a temporary greeting is being used, no other greetings are active. The temporary greeting can be selected for a certain number of days, the maximum number of days being 30. When you enter the number of days the end date is calculated and announced. When the temporary greeting time expires the greetings that you have assigned to specific call types are used. If you have no other greetings assigned the system default greeting will be played to callers.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.

2. Press **3** to select personal greetings.
 - If you have any active call types, you hear an announcement listing them. For example, *"For internal calls greeting 1 active"*.
 - If a temporary greeting is active, you hear how many days it will be active. To deactivate it, press **1**. To leave it active, press **#**.
3. Press **4** to administer call types.
4. Press **9** for temporary greeting.
5. Press **1** to record the greeting. Speak after the tone.
6. Press **#** when finished recording.
7. Enter the number of days that you want the greeting to be active for and press **#** when finished.
8. You will hear an announcement stating that your temporary greeting is active and the number of days that the greeting will remain active.
 - If the number of days selected is between 1 and 30, the greeting is active for the selected number of days. When the number of days has expired your temporary greeting no longer works.
 - If the number of days selected is 0, the selected greeting is your permanent greeting for all voicemail calls. The temporary greeting replaces the system default greeting.
9. To return to the greetings menu when you have finished, press **#**.

Related links

[Greetings](#) on page 30

Chapter 8: Voicemail Notification

If you have an Avaya 9600 Series or J100 Series phone, it will automatically provide message waiting indication to you for when a new message arrives in your mailbox. Your system administrator can also configure it to provide notification for messages in other mailboxes.

This section covers additional methods of receiving notification of a new message.

Related links

[Turning Ringback On or Off](#) on page 40

[Outcalling](#) on page 40

Turning Ringback On or Off

About this task

Ringback is a feature where the voicemail system calls you if you have new messages. It waits until your telephone is in use, to confirm that you are present, and calls you when you end your next call. You can switch voicemail ringback on or off at any time.

- Ringback is not the same as outcalling. Ringback works with your own extension number. Outcalling can be configured to call a number other than your own extension.

Procedure

At your extension:

- To turn ringback on, dial ***48**.
- To turn ringback off, dial ***49**.

Related links

[Voicemail Notification](#) on page 40

Outcalling

The voicemail service makes a call and if answered, tells you that you have a new message. You can then select to either cancel the notification or to login to your mailbox.

! Important:

- By default outcalling is disabled. Your system administrator will inform you if it is supported on your system.
- Your system administrator can configure your mailbox outcalling settings if required.

Destinations

You can define 5 outcalling destination numbers. These are called **Desk**, **Home**, **Mobile**, **Delegate** and **Other**. See [Configuring Your Outcalling Destinations](#) on page 42.

For each destination, you can also set how long it is rung when used.

Escalation List

You can add the destinations that you setup to an escalation list. Each time the system makes an outcalling call, if not answered at the first destination, it will try the next destination in your list.

Schedule

You can select to when outcalling is used, see [Selecting When to Receive Outcalling](#) on page 46. The defaults are:

- **Anytime:** 24 hours a day.
- **Prime times:** 09:00 to 19:30.
- **Peak times:** 09:00 to 17:30.

You can also define you own set of hours for when you want outcalling used. See [Specifying Your Own Time Schedule](#) on page 46.

Retries

If the system does not receive any response to an outcalling attempt (see [Answering Outcalling Calls](#) on page 47), it follows a retry schedule. The default schedule limits the number of retries to 5 and adds an increasing delay between each retry.

The default retry settings are:

- **1st Retry:** 1 minute.
- **2nd Retry:** 5 minutes.
- **3rd Retry:** 10 minutes.
- **4th Retry:** 15 minutes.
- **5th Retry:** 30 minutes.

Related links

[Voicemail Notification](#) on page 40

[Configuring Your Outcalling Destinations](#) on page 42

[Turning Outcalling On or Off](#) on page 42

[Changing Your Destination Telephone Numbers](#) on page 43

[Changing the Timeout Setting](#) on page 44

[Creating an Escalation List](#) on page 44

[Selecting When to Receive Outcalling](#) on page 46

[Specifying Your Own Time Schedule](#) on page 46

[Answering Outcalling Calls](#) on page 47

Configuring Your Outcalling Destinations

About this task

You can add or change the destinations and telephone numbers that outcalling uses. For each destination number you can set the time out length. This is the length of time (in seconds) that the destination telephone rings when notification of a new voicemail message is received. The default time is 15 seconds with the maximum time period being 99 seconds.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To change your outcalling settings, press **6**.
3. Press **1** to configure your outcalling options. A list of outcalling destinations is played.
4. Select the outcalling destination to configure. An announcement tells you your current outcalling settings.
 - If you selected the incorrect destination, for example Desk instead of Home, press **1**. The list of destinations is played again. Select the required destination.
5. Press **2** to change or enter the destination number.
6. Press **1**, enter the new destination number then press **#**. The telephone number entered is played back.
 - if you must re-enter the destination number, press **1**.
 - Press **#** to accept and enable the new destination.
7. If required, you can change the numbers ringing timeout:
 - a. To change the timeout, press **2**.
 - b. Enter the new value between 5 and 99 seconds and press **#**.
8. The new settings are played. Press **#** to accept and enable the new configuration.
9. Press ***7** to return to the activity menu.

Related links

[Outcalling](#) on page 40

Turning Outcalling On or Off

About this task

When outcalling is configured, you can control whether outcalling is active. You can also specify the times that outcalling is turned on. For more information, see [Selecting When to Receive Outcalling](#) on page 46.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.

2. To change your outcalling settings, press **6**.
3. Select the option required:
 - To turn outcalling on, press **9**.
 - To turn outcalling off, press **6**.
4. Press ***7** to return to the activity menu.

Related links

[Outcalling](#) on page 40

Changing Your Destination Telephone Numbers

About this task

You can change the telephone number of an outcalling destination or if no telephone number is defined you can enter a telephone number.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To change your outcalling settings, press **6**.
3. Press **3** to change a destination telephone number. Voicemail plays a list of possible destination options.
4. Select the destination to change.
 - Press **1** for Desk.
 - Press **2** for Home.
 - Press **3** for Mobile.
 - Press **4** for Delegate.
 - Press **5** for Other.
5. Voicemail announces the telephone number configured for the selected destination.
6. You can change the number if required:
 - a. Press **1**.
 - b. Press **1**, enter the new number and press **#** when finished.
 - c. Press **#** to enable the new telephone number.
7. Press **#** to return to the outcalling menu.
8. If required, you can change the numbers ringing timeout:
 - a. To change the timeout, press **2**.
 - b. Enter the new value between 5 and 99 seconds and press **#**.
9. Press ***7** to return to the activity menu.

Related links

[Outcalling](#) on page 40

Changing the Timeout Setting

About this task

For each destination number you can set a timeout. This sets how long time the destination is rung when called. The default time is 15 seconds.

If the destination specified is an internal number, outcalling will not go to voicemail if it is not answered. However, for external number care should be taken. For example, you should set the outcalling timeout to be shorter than your mobile phone's own voicemail setting.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To change your outcalling settings, press **6**.
3. Press **3** to change a destination telephone number. Voicemail plays a list of possible destination options.
4. Select the destination to change.
 - Press **1** for Desk.
 - Press **2** for Home.
 - Press **3** for Mobile.
 - Press **4** for Delegate.
 - Press **5** for Other.
5. Voicemail announces the telephone number configured for the selected destination.
6. Press **#** to return to the outcalling menu.
7. If required, you can change the numbers ringing timeout:
 - a. To change the timeout, press **2** .
 - b. Enter the new value between 5 and 99 seconds and press **#**.
8. Press ***7** to return to the activity menu.

Related links

[Outcalling](#) on page 40

Creating an Escalation List

About this task

You can create a list of your outcalling destinations, called an escalation list. Each time the system makes an outcalling call, if not answered by the first destination in the list, it will try the next destination and so on.

For example, you can select that new voicemail notification sent to your desk. If there is no response, the system can then call your mobile number. If again there is no response, it can call your home number.

When you create an escalation list you can select between two and five different destinations. If needed, you can add the same destination to your escalation list more than once.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To change your outcalling settings, press **6**.
3. Press **1** to configure outcalling.
4. Press **6** to select escalation.
5. Press **1** to change or configure the locations for escalation. An announcement of the locations available is heard.
6. Select the locations for the escalation. If you have not defined a number for the destination, you are prompted to enter the telephone number and the time out period or select a different destination.
 - Press **1** for Desk.
 - Press **2** for Home.
 - Press **3** for Mobile.
 - Press **4** for Delegate.
 - Press **5** for Other.
7. When you have selected the required locations, press **#** to finish the escalation list.
 - Press **1** to re-select the destinations.
 - Press **3** to listen to the destinations selected.
 - Press **4** to listen to the destinations and telephone numbers selected.
 - Press **2** to accept the list. You are returned to the outcalling main menu.

Next steps

When you have created an escalation list you can select to receive notification using the default settings of prime time, peak time or any time, see [Selecting When to Receive Outcalling](#) on page 46. You can also specify your own time schedule, see [Specifying Your Own Time Schedule](#) on page 46.

Related links

[Outcalling](#) on page 40

Selecting When to Receive Outcalling

About this task

You can select to receive outcalling notification during the prime or peak time periods. The time periods are set globally by your system administrator and may have been changed from the default setting. The default times are:

- **Anytime:** 24 hours a day.
- **Prime times:** 09:00 to 19:30.
- **Peak times:** 09:00 to 17:30.

Your system administrator can adjust the settings if required.

The times are based on the location of the voicemail server which may be different from your time zone. For details, contact your system administrator.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To change your outcalling settings, press **6**.
3. Press **2** to change the outcalling times:
 - To receive outcalling at any time, press **1**.
 - To receive outcalling during prime time periods, press **2**.
 - To receive outcalling during peak times, press **3**.
 - To specify your own outcalling schedule, press **4**. See [Specifying Your Own Time Schedule](#) on page 46.
 - To hear the system outcalling schedule. When the schedule times are announced you can select the time period.
4. You will hear an announcement of the new outcalling settings.

Related links

[Outcalling](#) on page 40

Specifying Your Own Time Schedule

About this task

You can create your own time profile to select when you will receive outcalling notification. You can change the times of each time period and select when to turn outcalling on. The default time profile is:

- From time A currently 9 am to time B currently 5.30 pm, outcalling is turned on/off.
- From time B currently 5.30 pm to time C currently 7.30 pm, outcalling is turned on/off.
- From time C currently 7.30 pm to time A currently 9 am, outcalling is turned on/off.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. To change your outcalling settings, press **6**.
3. Press **2** to change the outcalling times:
4. Press **4** to specify your own times.
5. Press **1** to change your time profile settings. You hear an announcement of the current settings for the time period A to B.
 - a. To change the destination, press **1**. Select the new destination (1 to 5). Press **#** to enable.
 - b. To turn outcalling on for all new messages, press **1**. To turn it on for just new priority messages, press **2**.
 - c. Press **2** to change time A.
 - d. Press **3** to change time B.
 - e. To accept the settings for the time period, press **#**.
6. You will hear the current settings for the time B to C settings.
 - a. To change the destination, press **1**. Select the new destination (1 to 5). Press **#** to enable.
 - b. To turn outcalling on for all new messages, press **1**. To turn it on for just new priority messages, press **2**.
 - c. Press **2** to change time C.
 - d. To accept the settings for the time period, press **#**.
7. You will hear the current settings for the time C to A settings.
 - a. To change the destination, press **1**. Select the new destination (1 to 5). Press **#** to enable.
 - b. To turn outcalling on for all new messages, press **1**. To turn it on for just new priority messages, press **2**.
 - c. To accept the settings for the time period, press **#**.
8. Press **#**. You are returned to the outcalling main menu.

Related links

[Outcalling](#) on page 40

Answering Outcalling Calls

About this task

When you are notified of a new voice message you hear the announcement “You have new messages. To access your messages, please enter your extension number and press hash. To avoid further notification of these messages, press star hash”.

If you do not answer the call or do answer but do not respond, the system will try the next number in your escalation list if you have one. See [Creating an Escalation List](#) on page 44. If there is no

answer from any number tried, the system will try outcalling again at a later time following the retry schedule. See [Outcalling](#) on page 40.

Procedure

1. Answer the telephone call.
2. When you hear the outcalling announcement:
 - To cancel the outcalling, press ***#**. The outcalling is cancelled for the current new message. You will still receive outcalling for any further new messages.
 - To answer the outcalling, press **#**. You can now login to voicemail as normal.

Related links

[Outcalling](#) on page 40

Chapter 9: Mailbox Administration

This section covers general mailbox tasks.

Related links

[Changing Your Password](#) on page 49

[Recording Your Name](#) on page 50

[Addressing a Message Before You Record](#) on page 50

[Preventing Further Calls and Messages](#) on page 51

[Setting the Order of Message Playback](#) on page 51

Changing Your Password

About this task

For security reasons, you should change your password periodically.

If necessary, your system administrator can set a new voicemail password for you. You can then use that password to access your mailbox and change the password.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **4** to change your password.
4. Enter the new password and press **#**.
 - You must enter at least 6-digits. The system allows up to 15-digits.
 - You cannot use your extension number, repeated digits or consecutive numbers.
 - You cannot use common key pad patterns such as 1397.
 - Your system administrator can change the minimum requirements and will inform you if they are different.
5. Reenter the new password and press **#**. You hear a message confirming if your password has changed.

Related links

[Mailbox Administration](#) on page 49

Recording Your Name

About this task

Your name is played as a confirmation when you log in to your mailbox. It is also used for other system announcements and for the directory search feature of the system. You can re-record your name at any time.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **5**. If you have already recorded your name, you hear it played back to you. You also hear an explanation of when your name is used.
4. After the tone, speak your name and then press 1 to stop recording.
 - Recordings must be at least 3 seconds long. The system will automatically delete any messages that are shorter.
5. Your recording is played back.
 - To record your name again, press **1**.
 - To accept the recording, press **#**.
6. Hang up or choose another option.

Related links

[Mailbox Administration](#) on page 49

Addressing a Message Before You Record

About this task

You can select whether to set the address for a message before or after you record. The default is off, which means that you set the address after recording the message. When switched on, you are asked to specify the extension numbers of the recipients before you record the message.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **6**. You hear a message that tells you whether the **Address before Record** option is turned on or off.
4. To change the setting, press **1**. You hear a message confirming your change.

Related links

[Mailbox Administration](#) on page 49

Preventing Further Calls and Messages

About this task

You can prevent further callers from leaving messages. Instead, callers hear your name and the message "Sorry, the mailbox you have reached is not accepting messages at this time. Please disconnect". This does not stop other mailbox users from forwarding messages to your mailbox.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **7**. You hear a message that tells you whether the option is on or off.
4. To change the setting, press **1**. You hear a message confirming the change.

Related links

[Mailbox Administration](#) on page 49

Setting the Order of Message Playback

About this task

When you log into your mailbox, messages are played to you in the order in which they were received. You can specify the order in which different types of incoming messages (voice, email and fax) are played. For example, you can choose to hear emails first or fax messages before voice messages.

Whichever order you specify, new messages are presented first followed by old or read messages. While you are listening to your messages, you can press ***#** to skip to the next type of message.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **8** for media preferences. You hear an announcement telling you your current preference.
 - To select no preference, press **0**.
 - To make voice calls your preferred media, press **1**. Your voice messages will be played first, followed by fax and then email messages.
 - To make fax messages your preferred media, press **2**. Your fax messages will be played first, followed by voice and then email messages.
 - To make email messages your preferred media, press **3**. Your email messages will be played first, followed by voice and then fax messages.

- To retain your current preferred media, press #.

Related links

[Mailbox Administration](#) on page 49

Chapter 10: Fax Messages

Your voicemail system can be configured to handle fax messages. If so, when you listen to your messages, you are told which are faxes and can hear details of the fax sender, date and time and length (approximate pages).

You can then manually forward fax messages to either the systems default fax number or to a number you specify at the time.

You can also configure a personal fax number to which you want any faxes received by your mailbox automatically forwarded.

Related links

[Forwarding a Fax Messages](#) on page 53

[Setting a Personal Fax Number](#) on page 54

[Deleting Your Personal Fax Number](#) on page 54

Forwarding a Fax Messages

About this task

If you receive a fax message in your mailbox, you can forward it to the default system-wide fax number, typically your company fax machine. Alternatively, you can forward a fax message to a fax number that you specify, see [Setting a Personal Fax Number](#) on page 54.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. If any of your messages are faxes, press *1 for fax options.
3. Either:
 - Press # to forward the fax message to the system fax number. Press # to confirm.
 - Type the number to which the fax is to be forwarded and press #. The fax number that you have specified is played back to you for confirmation.

Related links

[Fax Messages](#) on page 53

Setting a Personal Fax Number

About this task

If your system administrator has set a system fax number, any fax calls to your mailbox are diverted to the specified number. You can override this from your telephone handset and set your own personal number for printing fax calls that are received in your mailbox. This is useful if you are not in the office and want to use a different fax number.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **3** for fax preferences.
4. If you hear the prompt "A *default print destination has not been defined*" this is because a default system fax number has not been set. You cannot set up a personal fax number until a default system fax number is set by your system administrator. Press ***7** to return to the activity menu.
5. If a personal fax print number is already set, it is played to you. Press **1** to change the default fax destination.
 - a. Enter the telephone number of the fax machine that you would prefer to use instead. The fax number can be up to 23 digits long.
 - b. Enter **#** when you have finished typing the fax number. The new default destination is played to you.
6. Press ***7**.

Related links

[Fax Messages](#) on page 53

Deleting Your Personal Fax Number

About this task

You can delete a personal fax number, if you have set one, and return to using the system fax number.

Procedure

1. Log in to your mailbox. See [Logging In](#) on page 11.
2. Press **5** for personal options.
3. Press **3** for fax preferences. If you have a personal fax number set, voicemail plays it to you.

4. Press ***3** to delete the personal fax number. Your personal fax number is deleted and the system fax number is played to you. The system fax number is now used for any future fax messages that you receive.

Related links

[Fax Messages](#) on page 53

Chapter 11: Visual Voice

Visual Voice allows you to navigate your voicemail mailbox and settings using menus displayed on your phone rather than following spoken prompts.

Related links


[Logging into Visual Voice](#) on page 12

[Visual Voice Controls](#) on page 57

Logging into Visual Voice


About this task

Visual voice is a set of Avaya phone menus that you can use to access your mailbox and the mailbox settings.

By default, the  button on Avaya phones accesses the visual voice menus for the phone user's mailbox.

- Your system administrator can also configure the visual voice menus for your phone to provide access to messages in other users and groups mailboxes.

Procedure

1. Either:
 - a. Press the  button on your Avaya phone.
 - b. Press **Features**. Scroll down to **Visual Voice** and press **Select**.
 - c. Press the optional **Visual Voice** button that has been programmed on your phone.
2. The visual voice options should appear on the phone's screen. See [Visual Voice Controls](#) on page 57.

Related links

[Logging Into Your Mailbox](#) on page 10

[Visual Voice](#) on page 56

Visual Voice Controls

The arrangement of options on the screen varies depending on the phone type and display size.

Label	Description
Listen	<p>Access your own voicemail mailbox and see the number of different types of messages. Select one of the options to access those messages and use the options below:</p> <ul style="list-style-type: none"> • Play: Play the message. <ul style="list-style-type: none"> - To select the next message or previous message, use the phone's up and down cursor keys. - To fast forward or rewind the current playing message by 5 seconds, use the phone's left and right cursor keys. • Pause: Pause the message playback. • Delete: Delete the message. • Call : Call the message sender if a caller ID is available. • Copy: Copy the message to another mailbox. When pressed, a number of additional options are displayed.
Message	Record and send a voicemail message to another mailbox or mailboxes.
Greeting	Change the main greeting used for callers to your mailbox. If no greeting has been recorded, the default system mailbox greeting is used.
Passcode	Change the voicemail mailbox password. To do this requires entry of your existing password.
Email	<p>This option appears if you have been configured with an email address. You can see and change the current voicemail email mode being used for new messages received by your voicemail mailbox. Use Change to change the selected mode. Press Done when the required mode is displayed. The modes are:</p> <ul style="list-style-type: none"> • Email Mode Off: Voicemail email is not used. • Email Mode Copy: Copy new voice messages to your email address, leaving the original message in the mailbox. • Email Mode Fwd: Forward new voice messages to your email address, deleting the original message from the mailbox. • Email Mode Alert: Send an alert email message to your email address, leaving the message in the mailbox.
Voicemail	Switch voicemail coverage on/off. When off, your system does not redirect unanswered calls to your mailbox.

Related links

[Visual Voice](#) on page 56

12장: 추가 도움말 및 문서

다음 페이지에서는 추가 도움말을 볼 수 있습니다.

관련 링크

[암호 분실](#) (58 페이지)

[도움말 받기](#) (58 페이지)

[추가 문서](#) (59 페이지)

암호 분실

일부 IP Office 기능을 사용하려면 사용자 이름, 암호, 로그인 코드(보안 PIN), 음성 메일함 코드(사서함 암호)와 같은 정보를 입력해야 합니다.

Avaya는 암호 및 코드의 값을 재설정하거나 재설정할 수 없습니다. 그러나 필요한 경우 시스템 관리자는 값을 직접 또는 Avaya 비즈니스 파트너에게 요청하여 값을 재설정할 수 있습니다.

또한 시스템 관리자는 허용되는 암호 및 코드에 대해 IP Office 시스템이 사용하는 규칙을 설정합니다. 모든 사용자에게 동일한 규칙이 적용됩니다.

관련 링크

[추가 도움말 및 문서](#) (58 페이지)

도움말 받기

Avaya는 공인 비즈니스 파트너를 통해 IP Office를 판매합니다. 이러한 비즈니스 파트너는 고객에게 직접 지원을 제공하고 필요한 경우 Avaya에 문제를 에스컬레이션합니다.

추가 지원이 필요한 경우 먼저 시스템 관리자에게 문의해야 합니다. 시스템 관리자는 IP Office 시스템의 전체 구성에 액세스할 수 있으며, 직접 또는 시스템의 Avaya 비즈니스 파트너에게 요청하여 액세스할 수 있습니다.

시스템 관리자/리셀러가 기존 암호를 볼 수 없는 경우, 이들은 사용자가 다시 로그인하여 값을 변경할 수 있도록 암호를 재설정할 수 있습니다.

관련 링크

[추가 도움말 및 문서](#) (58 페이지)

추가 문서

[Avaya Documentation Center](#) 웹사이트에는 Avaya 제품용 사용자 안내서와 설명서가 포함되어 있습니다. 아래 링크는 유용한 사용자 가이드를 다룹니다.

전화기 사용자 안내서

- [IP Office J100 Series Phone User Guide](#) | [IP Office J100 Series Quick Reference](#)
- [IP Office 9600 Series Phone User Guide](#) | [IP Office 9600 Series Quick Reference](#)
- [IP Office Analog Phone User Guide](#)

애플리케이션 안내서

- [Using Avaya Workplace 클라이언트 for IP Office](#)
- [Using the IP Office User Portal](#)
- [Using one-X Portal for IP Office](#)
- [Using IP Office SoftConsole](#)

음성 메일 사서함 사용자 안내서

- [Using a Voicemail Pro IP Office Mode Mailbox](#)
- [Using a Voicemail Pro Intuity Mode Mailbox](#)
- [Using IP Office Embedded Voicemail Intuity Mode](#)
- [Using IP Office Embedded Voicemail IP Office Mode](#)

관련 링크

[추가 도움말 및 문서](#) (58 페이지)

Index

Special Characters

관리자	58
도움말	58
로그인 코드	58
리셀러	58
문서	59
보안 PIN	58
비밀번호	58
비밀번호 분실	58
비즈니스 파트너	58
사용자 안내서	59
설명서	59
시스템 관리자	58
음성 메일 코드	58

A

Accept Call Answer	51
Address Before Record	50
Alert	40
Answer	
Outcalling	47
Automatic deletion	7

B

Breakout options	22
------------------------	--------------------

C

Call sender	15
Callback	15
Caller options	22
Change	
Name recording	50
Password	49
Change a greeting	37
Collect messages	14
Create a mailing list	24

D

Delete	
Automatic	7
Greeting	38
Mailing list	28
Message	15
Distribution List	
See Mailing lists	24

E

Email	
Voicemail Email	57
Embedded Voicemail	6
Escalation list	44

F

Fax	53
Delete personal number	54
Forward	53
Personal number	54
Forward	
Fax messages	53
To a mailing list	29
Forward a message	16

G

Greeting	
Breakout	22
Skip	22
Greetings	30
Activate a greeting	34
Assign	32
Change a greeting	37
Deactivate a greeting	35
Delete a greeting	38
Listen to	36
Record a greeting	31
Scan greetings	36
Temporary greeting	38
Unassign	33

I

Intuity mode	6
IP Office mode	6

L

Listen to greetings	36
Listen to messages	14, 15
Login	10
After leaving a message	23
First Time	10
From an external number	12
Normal	11
Remote	12
Visual Voice	12, 56

M

Mailbox	
Controls	7
Off	51
Options	7
Mailbox code	49
Mailbox mode	6
Mailing lists	24
Adding members	27
Create a list	24
Delete a list	28
Forward to	29
Private	26
Public	26
Removing members	27
Reviewing lists	25
Using a list	28
Mark as	
Priority	23
Private	23
Message	
Call sender	15
Delete	15
Forward	16
Reply to a message	16
Send a new message	17
Message waiting indication	40
Messages	
Collect	14
Fax	53
Listen	14
New message indication	40
Playback order	51
Record a new messages	20
Scan	18

N

Name	50
Notification	40

O

Operator	22
Order of playback	51
Outcalling	40
Answer	47
Destinations	42, 43
Escalation list	44
Numbers	43
Off	42
On	42
Peak Time	46
Personal times	46
Prime time	46
Retries	40

Outcalling (continued)

Ring time	44
Schedule	46
Timeout	44

P

Password	49
Pause	15
Personal Distribution Lists	
See Mailing lists	24
Personal fax number	
Change	54
Delete	54
Playback order	51
Post message options	23
Priority	23
Private	23
Mailing list	26
Public	
Mailing list	26

R

Receptionist	22
Record	
Name	50
Record a greeting	31
Record a new message	17, 20
Reply to a message	16
Replay order	51
Reply	16
Resume	15
Reviewing mailing lists	25
Ringback	40

S

Scan	
Greetings	36
Mailing lists	25
Scan your messages	18
Send a message	17
Skip greeting	22
Storage limit	7
Summary	7

T

Temporary greeting	38
Transfer	21

U

User guides	6
Using a mailing list	28

V

Visual Voice	56
Login	12 , 56
Options	57
Voicemail code	49
Voicemail Email	57
Voicemail Pro	6
Voicemail ringback	40