



Using IP Office Embedded Voicemail IP Office Mode

Release 12.0
Issue 3
May 2022

Notices

© 2026 Avaya LLC. All Rights Reserved.

You may, at your own risk, assemble a MyDocs collection solely for your own internal business purposes, which constitutes a modification to the original published version of the publications. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of publications. You agree to defend, indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, your modifications, additions or deletions to the publications.

A single topic or a collection of topics may come from multiple Avaya publications. All of the content in your collection is subject to the legal notices and disclaimers in the publications from which you assembled the collection. For information on licenses and license types, trademarks, and regulatory statements, see the original publications from which you copied the topics in your collection.

Except where expressly stated by Avaya otherwise, no use should be made of materials provided by Avaya on this site. All content on this site and the publications provided by Avaya including the selection, arrangement and design of the content is owned by Avaya and/or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. Avaya owns all right, title and interest to any modifications, additions or deletions to the content in the Avaya publications.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published in varying media which may include product information, subscription or service descriptions, operating instructions and performance specifications that are generally made available to users of products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless such modifications, additions, or deletions were performed by or on the express behalf of Avaya. End user agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End user.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or Documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on Avaya hardware and software. Please refer to your agreement with Avaya to establish the terms of the limited warranty. In addition, Avaya's standard warranty language as well as information regarding support for this product while under warranty is available to Avaya customers and other parties through the Avaya Support website: <https://support.avaya.com/helpcenter/getGenericDetails?detailId=C20091120112456651010> under the link "Warranty & Product Lifecycle" or such successor site as designated by Avaya. Please note that if the product(s) was purchased from an authorized Avaya channel partner outside of the United States and Canada, the warranty is provided by said Avaya Channel Partner and not by Avaya.

"Hosted Service" means an Avaya hosted service subscription that You acquire from either Avaya or an authorized Avaya Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Avaya or Avaya Channel Partner (as applicable) for more information.

Hosted Service

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN AVAYA HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE). THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA WEBSITE, [HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO](https://support.avaya.com/licenseinfo) UNDER THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE

TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE.

Licenses

The Global Software License Terms ("Software License Terms") are available on the following website <https://www.avaya.com/en/legal-license-terms/> or any successor site as designated by Avaya. These Software License Terms are applicable to anyone who installs, downloads, and/or uses Software and/or Documentation. By installing, downloading or using the Software, or authorizing others to do so, the end user agrees that the Software License Terms create a binding contract between them and Avaya. In case the end user is accepting these Software License Terms on behalf of a company or other legal entity, the end user represents that it has the authority to bind such entity to these Software License Terms.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Avaya. All content on this site, the documentation, Hosted Service, and the product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Unless otherwise stated, each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two Instances of the same type of products, then two products of that type must be ordered.

Third Party Components

The following applies only if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).

Service Provider

WITH RESPECT TO CODECS, IF THE AVAYA CHANNEL PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED THE H.264 CODEC OR H.265 CODEC, THE AVAYA CHANNEL PARTNER ACKNOWLEDGES AND AGREES THE AVAYA CHANNEL PARTNER IS RESPONSIBLE FOR ANY AND ALL RELATED FEES AND/OR ROYALTIES. THE H.264 (AVC) CODEC IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO: (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).

Compliance with Laws

You acknowledge and agree that it is Your responsibility to comply with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Avaya product is used.

Preventing Toll Fraud

“Toll Fraud” is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If You suspect that You are being victimized by Toll Fraud and You need technical assistance or support, please contact your Avaya Sales Representative.

Security Vulnerabilities

Information about Avaya's security support policies can be found in the Security Policies and Support section of <https://support.avaya.com/security>.

Suspected Avaya product security vulnerabilities are handled per the Avaya Product Security Support Flow (<https://support.avaya.com/css/P8/documents/100161515>).

Trademarks

The trademarks, logos and service marks (“Marks”) displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, its licensors, its suppliers, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya LLC.

All non-Avaya trademarks are the property of their respective owners.

Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: <https://support.avaya.com>, or such successor site as designated by Avaya.

Contact Avaya Support

See the Avaya Support website: <https://support.avaya.com> for Product or Cloud Service notices and articles, or to report a problem with your Avaya Product or Cloud Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <https://support.avaya.com> (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

Contents

Chapter 1: Embedded Voicemail IP Office Mailbox User	5
Chapter 1: Embedded Voicemail	6
Which Voicemail Do I Have?.....	6
Logging in normally.....	7
Trusted sources introduction.....	7
Default mailbox controls.....	7
Caller options overview.....	9
Full mailbox introduction.....	9
Chapter 2: Listen to messages	10
Listening to your messages.....	10
Saving a message.....	11
Forwarding a message.....	11
Calling the sender.....	11
Chapter 3: Change your mailbox settings	12
Changing your password.....	12
Trusted sources and system administration.....	12
Recording your greeting.....	13
Listening to your greeting.....	14
Transfer options overview.....	14
Recording your name.....	14
Chapter 4: Voicemail notification	16
Chapter 5: Voicemail Email	17
Switching on email notification.....	17
Switching off email notification.....	18
Chapter 6: Outcalling	19
Configuring initial outcalling.....	19
Setting your outcalling destination.....	20
Setting your outcalling timeout.....	21
Turning outcalling on.....	21
Turning outcalling off.....	22
Answering outcalling calls.....	22
Cancel message notification.....	22
Chapter 7: Visual voice introduction	23
Visual voice controls.....	23
Chapter 8: Additional Help and Documentation	26
Forgotten Password.....	26
Getting Help.....	26
Additional Documentation.....	27

Chapter 1: Embedded Voicemail IP Office Mailbox User

Chapter 1: Embedded Voicemail

This document covers mailbox operation on IP Office system using Embedded Voicemail running in Intuity mailbox mode. If you are not sure which system you have and the mode it is operating in, see [Which Voicemail Do I Have?](#) on page 6.

Which Voicemail Do I Have?

How to work out which mailbox guide to use?

IP Office supports several types of voicemail, so it is important that you use the correct mailbox guide. Your system administrator can tell you which guide to use.

You can also use the following process to try and work out which guide to use for yourself. However, due to the customizability of IP Office voicemail, this may not always work.

1. On your phone, dial ***17** to access voicemail.
2. After the initial greeting, if voicemail asks “*Please enter extension and pound key*” it is running in a mode called 'Intuity emulation' mode. Otherwise, go to step 4.
3. Press **7**.
 - a. If the voicemail responds with a set of scan options, your voicemail server is called Voicemail Pro. Use the [Using a Voicemail Pro Intuity Mode Mailbox](#) user guide.
 - b. Otherwise, your voicemail server is called Embedded Voicemail. Use the [Using a Voicemail Pro IP Office Mode Mailbox](#) user guide.
4. If otherwise, your voicemail system is running in a mode called 'IP Office' mode. Press ***05**.
 - a. If the voicemail responds with a set of options, your voicemail server is called Embedded Voicemail. Use the [Using IP Office Embedded Voicemail Intuity Mode](#) user guide.
 - b. Otherwise, your voicemail server is called Voicemail Pro. Use the [Using IP Office Embedded Voicemail IP Office Mode](#) user guide.

Logging in normally

Procedure

1. At your own extension, dial *17.
2. If requested, enter your password and press #.

The system requests a password if you are accessing a mailbox from a number not set as a trusted source for that mailbox.

3. After you log in, the voice prompts provide instructions. See Default Mailbox Controls for a summary of the controls.
 - For help at any time: Press *4.
 - To return to the activity menu: Press 8.

Trusted sources introduction

By default, even when you have a password set, you can access your mailbox from your own extension without needing to use the password. This is because your extension number is set as a 'trusted source'. Your system maintainer can change that if required. They can also add other numbers as trusted sources for your mailbox if required.

Mailbox access from numbers that are not trusted sources requires entry of your mailbox password.

Example

Entry of your password is usually required if your maintainer has configured a method for you to access your mailbox from remote locations other than your own extension.

Default mailbox controls

The following is a summary of the options that are available after you have logged into a mailbox.

<p>New messages start playing by default.</p> <ul style="list-style-type: none"> • Play old messages = 1 • Play saved messages = 2 • Fast forward = # • Rewind = * • Repeat last message = 7 • Skip current message = 9 • Delete current message = 4 • Save current message = 5 • Mark Message as new = *06 • Call back sender = ** • Forward message = 6 	<p>Configuration</p> <ul style="list-style-type: none"> • Edit greeting = 3 • Record Name = *05 • Change mailbox code = *04 • Direct all to email = *01 • Send email notification = *02 • Turn email off = *03 • Outcalling options = *07 • Help = *4
<p>3. Edit Greeting</p> <ul style="list-style-type: none"> • Listen to greeting = 1 • Record new greeting = 2 • Save new greeting = 3 • Save new greeting as a loop = 4 • Return to mailbox = 8 	<p>6. Forwarding</p> <ul style="list-style-type: none"> • Forward to extensions = 2 • Forward with header message = 3 <p>[Follow each extension number with # and then a final # to finish.]</p>
<p>*07. Outcalling</p> <ul style="list-style-type: none"> • Listen to settings = 0 • Configure outcalling = 1 • Turn outcalling off = 6 • Turn outcalling on = 9 • Return to mailbox = 8 	

*** Note:**

Old Messages are automatically deleted after 24 hours.

After you listen to new message, it is marked as 'old' and it is automatically deleted after 24 hours. If you do not want the message deleted, you must mark it as a 'saved' message.

- To mark the current message as saved, press **5** while listening to the message.

You can also use the following short codes to control your mailbox. These are default system features, however your system maintainer can change them. For users with Avaya telephones that include programmable buttons, your system administrator can also assign these functions to buttons.

- **Turn Voicemail On: *18**

Causes calls to go to voicemail when you are busy or do not answer. If the extension to which you forward your calls does not answer calls will also go to voicemail.

- **Turn Voicemail Off: *19**
- **Voicemail Ringback On: *48**

If ringback is on, when you have new messages, the voicemail system will ring you following the completion of any call.

- **Voicemail Ringback Off: *49**

Caller options overview

Callers to your mailbox can perform the following actions:

- **Skip Your Mailbox Greeting:** Callers can skip your greeting message and go straight to leaving a message by pressing **1**.
- **Transfer to another number:** Depending on your settings, the caller can select a transfer to another extension rather than leaving a message.
- **Leave a message:** After hearing the tone, your caller can start recording a message. The system only saves messages that are longer than 3 seconds. The default maximum message length is 120 seconds. However, the system administrator can adjust that.
- **Options after leaving a message:** After leaving a mailbox message, callers can press **#** rather than hanging up immediately. The caller hears a prompt informing them if the system saved the message. The system then disconnects the call.

Full mailbox introduction

When a mailbox is full and unable to store new voicemail messages, the voicemail system plays an information message and disconnects the call.

Chapter 2: Listen to messages

This section covers actions you can perform while listening to your messages.

The system groups messages into the following categories:

- **New:** After you have listened to a new message, it automatically becomes an old message.
- **Saved:** This category applies to messages you marked as saved . You would normally do this for messages that you do not want the system to automatically delete.
- **Old:** After you have listened to a new message it automatically becomes an old message. Unless you delete them sooner, the system automatically deletes old messages after 24 hours.

When you get your messages, the system automatically starts playing your new messages if you have any. After each message, the system plays details of when the message was left and the caller.

Listening to your messages

Procedure

1. Log in to your mailbox.
2. If you have any new messages, the system starts playing them.
 - To switch to playing old messages: Press **1**.
 - To switch to playing saved messages: Press **2**.
3. While playing a message, you can use the following options:
 - To fast forward: Press **#**.
 - To rewind: Press *****.
 - To repeat the last message: Press **7**.
 - To skip the current message: Press **9**.
 - To delete the current message: Press **4**.
 - To mark the message as saved: Press **5**.
 - To call back the sender: Press ******.
 - To forward the message: Press **6**.

Saving a message

About this task

Once you have played a message it is marked as old. The system automatically deletes old messages after 24 hours. To stop this happening to the current message, you can mark it as being a saved message.

Procedure

Press **5** when listening to a new or old message.

Forwarding a message

About this task

You can forward a message to a different mailbox or to several mailboxes at the same time. When you do this, you can record a comment at the start of the message.

Procedure

1. While listening to the message, press **6**.
 - To forward the message as is, press **2**.
 - To add a comment before forwarding, press **3**. After the tone, record your comment and press **#** to finish recording.
2. Enter the extension number to forward the message and press **#**.
3. If you want to send the message to more than one extension, repeat the process of enter each extension number followed by **#**.
4. Press **#** to finish addressing and forward the message.

Calling the sender

About this task

When an internal caller leaves a message, the system will capture the caller's number and store that with the message. You can choose to make a call to the caller's number.

Procedure

While listening to a message, press ******.

Chapter 3: Change your mailbox settings

This section covers the changing general mailbox settings.

Changing your password

About this task

You are not required to set a password for your mailbox if you only access it from your own extension. For access to your mailbox from other locations, including in response to Outcalling, you will need to have a password set. If you do set a password it is used, however when accessing your mailbox from certain trusted sources (see below), you will not need to enter it. By default, the system sets your extension as a trusted source.

Procedure

1. Log in to your mailbox.
2. Press ***04** to change your password.
3. Enter your current password and press **#**. If you have no current password just press **#**.
4. Enter your new password followed by **#**.

Enter at least four digits and up to 15. Do not set an obvious code. For example:

- Your extension number.
 - A sequence of digits, for example 1234.
 - The same repeated digits, for example 1111.
5. Re-enter your new password followed by **#**.
 - The system will prompt you if the codes do not match or is not acceptable. It will also confirm the change of password if successful.

Trusted sources and system administration

By default, even when you have a password set, you can access your mailbox from your own extension without needing to use the password. This is because your extension number is set as

a 'trusted source'. Your system maintainer can change that if required. They can also add other numbers as trusted sources for your mailbox if required.

Mailbox access from numbers that are not trusted sources requires entry of your mailbox password. For example, entry of your password is usually required if your maintainer has configured a method for you to access your mailbox from remote locations other than your own extension.

System Administration

The system administrator cannot see your password. However, they are able to clear your existing password.

Recording your greeting

About this task

By default, callers to your mailbox hear the default system greeting. You can replace this with a personal greeting.

You can record the greeting heard by callers to your voicemail. At any time, you can listen to a greeting message and re-record it.

A greeting must be longer than 3 seconds. The maximum length of a greeting is 120 seconds by default.

Procedure

1. Log in to your mailbox.
2. Press **3** to select the option to edit your greeting.
3. Press **2** to change your greeting.
4. When prompted, speak your new greeting.
 - The greeting must be longer than 3 seconds.
 - A long (approximately 10 seconds) period of silence will disconnect you from voicemail.
5. Press **2** when you have finished recording your greeting.
6. Press **1** to listen to your new greeting. After you have listened to your greeting:
 - To save the new greeting: Press **3**.
 - To re-record the new greeting: Press **2**.
 - To save the new greeting as a continuous loop: Press **4**.

Callers are not able to leave messages.

Note:

When you select this option, you can only change the greeting back to a normal greeting by recording a new greeting.

Listening to your greeting

About this task

If you want to check your greeting, use the following process.

Procedure

1. Log in to your mailbox.
2. Press **3** to select the option to edit your greeting.
3. Press **1** to hear your greeting.

If no greeting has been recorded you will hear "The message has not yet been recorded".

Transfer options overview

Your system administrator can set up to 3 transfer numbers for your mailbox. When a caller to your mailbox presses **0**, **2** or **3**, the system transfers them to the matching number configured by your system administrator. Typically, this feature allows the system to transfer callers to the receptionist or one of your colleagues.

Contact your system administrator to find out if they have set any transfer numbers for your mailbox. When this feature is set, remember to alter your mailbox greeting in order to inform callers of the options they can use.

Recording your name

About this task

You hear your name played as a confirmation when you log in to your mailbox. The system also uses it for other system announcements and functions. You can change your name recording at any time.

Procedure

1. Log in to your mailbox.
2. Press ***05** to select the option to record your name.
3. Press **1** to hear your current recording.
4. Press **2** to record your name. When prompted, speak your name.

The maximum recorded length is 5 seconds.

5. Press **2** when you have finished recording your name.

6. Press **1** to listen to your new recording. Review the recording and select one of the following options:
 - To save the new recording: Press **3**.
 - To record your name again: Press **2**.

Chapter 4: Voicemail notification

There are several ways that the system can alert you when you have a new message.

- **Message Waiting Lamp:** Most Avaya telephones include a message waiting lamp, typically at the top right of the phone. This lamp lights when your mailbox contains any new messages that you have not heard. In addition, many Avaya phones have a MESSAGE button which also lights when your mailbox contains new messages.
 - Your system administrator can also configure your message indicators to light when a group mailbox contains new messages. You can then see and access that additional mailbox through **Visual Voice**.
- **Ringback:** If you enable ringback, whenever you use your phone, immediately after completing the call the system will automatically call you if your mailbox contains any new messages. This is useful if you have a telephone that does not have a message waiting lamp or button.
 - To switch ringback on: Dial ***48**.
 - To switch ringback off: Dial ***49**.
- **Outcalling:** Outcalling allows you to specify a number that the system calls when your mailbox contains any new messages. If you answer the call, the system prompts you to login to hear your messages.
- **Voicemail Email:** The voicemail system can send an email whenever your mailbox receives a new message. The email can be just a simple alert that you have a new message or it can also include an attached copy of the message.

Chapter 5: Voicemail Email

You can have notification of new messages sent to your email address. The notification can be a simple alert to tell you that you have a message or a copy of the voicemail message if required.

- **Email Address/Enabling Voicemail Email Functions**

Before you can use the email options, your system administrator must enter your email address into the telephone system configuration. Otherwise, you hear the message 'Email is not enabled on this mailbox' whenever you try to use an email option. Your system administrator can tell you whether they have configured your mailbox to use email.

- In addition to the functions described in this section, if you have an Avaya telephone that supports Visual Voice, you can use **Visual Voice** to control your **Voicemail Email** settings. See [Visual voice introduction](#) on page 23.

Related links

[Switching on email notification](#) on page 17

[Switching off email notification](#) on page 18

Switching on email notification

About this task

When you switch on email notification, you can also select the type of notification required.

Procedure

1. Log in to your mailbox.
2. Select the required type of email notification.
 - For an email alert: Press ***02**. When you have a new voicemail message in your mailbox, you will receive an email advising you of this.
 - To have the message forwarded to your email: Press ***01**. When you have a new voicemail message in your mailbox, the system forwards it to your email address as an attachment. The system deletes the original message from your mailbox.

Related links

[Voicemail Email](#) on page 17

Switching off email notification

About this task

You can turn off email notification when it is not required. Doing this does not change your other email settings.

Procedure

1. Log in to your mailbox.
2. Press ***03**.

You hear a confirmation message.

Related links

[Voicemail Email](#) on page 17

Chapter 6: Outcalling

You can receive notification of a new voice message by using the outcalling feature. When you receive a new message, the voicemail system notifies you by calling a number that you have set. You can then retrieve the message from the number at which you received the notification. Systems running Release 7.0 or higher support this option.

Each outcalling alert rings for a duration you can set. The default is 15 seconds. The call ends if not answered. If answered, the system prompts you to enter your mailbox password. When answer, the outcalling call automatically ends if:

- You press ***#** to indicate that you do not want any more outcalling calls for the current new messages.
- You enter the wrong password 3 times.
- More than 5 minutes passes with no response.

Up to 3 outcalling calls are attempted, with a minimum of 15-minutes between calls, unless you answer and press ***#** or access your mailbox by another method. If you receive any more new messages in the meantime they do not restart the outcalling attempts.

Related links

[Configuring initial outcalling](#) on page 19

[Setting your outcalling destination](#) on page 20

[Setting your outcalling timeout](#) on page 21

[Turning outcalling on](#) on page 21

[Turning outcalling off](#) on page 22

[Answering outcalling calls](#) on page 22

Configuring initial outcalling

About this task

The first time you access the outcalling menus, the system prompts you to set a destination number for outcalling alerts.

Once set, you can then change the number, turn outcalling on, turn outcalling off and change the timeout used for how long outcalling calls ring.

Procedure

1. Press ***07**.

An announcement tells you that you have not configured outcalling.

2. Press **1** to configure your outcalling options.

You need to specify the destination telephone number where you want to receive your new voicemail notification.

3. When you have configured an outcalling destination number, you can turn outcalling on/off.

Related links

[Outcalling](#) on page 19

Setting your outcalling destination

About this task

You can add or change the telephone number that outcalling uses.

Procedure

1. Log in to your mailbox.
2. Press ***07** to access your outcalling settings.
3. Press **1**.
4. Press **2** for number entry.
5. Press **1** and then enter the number that you want outcalling to call. Remember to include any external dialing prefix that you would normally dial to make the call.
 - **A *** in the number is treated as a pause (1.5 seconds) in the dialing.
 - To enter a **#** into the number: Dial ***#**.
 - You can also use internal numbers as your outcalling destination. The calls will follow any internal forwarding and will honor do not disturb. However, the outcalling attempt ends if the call goes to voicemail.
6. Press **#** to finish number entry.

Related links

[Outcalling](#) on page 19

Setting your outcalling timeout

About this task

The timeout controls how long the outcalling call rings the destination number before hanging up if not answered. The default is 15 seconds with the maximum being 59 seconds.

If the destination specified is an internal number, outcalling does not go to voicemail if unanswered. However, if the destination is an external number with its own voicemail, the timeout must be set to less than the time before the external voicemail might answer. For example, if you have voicemail active for your mobile telephone, where any calls go to voicemail if not answered after 30 seconds, you must set the outcalling timeout to less than 30 seconds.

Procedure

1. Log in to your mailbox.
2. Press ***07** to access your outcalling settings.
3. Press **1**.
4. Press **3** for timeout entry.
5. Enter a number between 5 and 59 and then press **#**.

Related links

[Outcalling](#) on page 19

Turning outcalling on

About this task

Once you have a set an outcalling destination, you can choose to switch outcalling on.

Procedure

1. Log in to your mailbox.
2. Press ***07** to access your outcalling settings.
3. Press **9** to switch outcalling on.

Related links

[Outcalling](#) on page 19

Turning outcalling off

About this task

You can turn outcalling off. Doing this does not delete the outcalling number or timeout you have set.

Procedure

1. Log in to your mailbox.
2. Press ***07** to access your outcalling settings.
3. Press **6** to switch outcalling off.

Related links

[Outcalling](#) on page 19

Answering outcalling calls

About this task

When you have a new message, the system tries to call your outcalling destination number three times with a 15-minute interval between each call.

Procedure

1. Answer the outcalling alert.
2. When you hear the outcalling announcement, enter your extension number and press **#**.
Log in to voicemail in the usual way and collect your new message.

Related links

[Outcalling](#) on page 19

[Cancel message notification](#) on page 22

Cancel message notification

About this task

Procedure

1. Answer the outcalling alert.
2. When you hear the outcalling announcement, enter ***#**.

The system cancels any further outcalling for that new message. You still receive outcalling alerts for any subsequent new message.

Related links

[Answering outcalling calls](#) on page 22

Chapter 7: Visual voice introduction

Visual Voice allows you to access your mailbox using the display menu of your phone rather than following spoken mailbox prompts. Not all phones support Visual Voice.

To use Visual Voice your system maintainer must add a **Visual Voice** button to your phone. Alternatively, your system maintainer can set the MESSAGES button on your phone to act as a **Visual Voice** button.

- On phones that have a display but do not support visual voice operation, use of the button for user mailbox access using voice prompts and for direct to voicemail transfer during a call is supported (does not include T3 and T3 IP phones).
- On T3 phones, the **Visual Voice** button goes direct to the **Listen function of Visual Voice**. To access the full set of Visual Voice functions use **Menu > Settings > Voicemail Settings**.

Using visual voice button for voicemail transfer

If pressed when you have a call is connected, the **Visual Voice** button allows entry of an extension number for direct to voicemail transfer of the connected call.

Related links

[Visual voice controls](#) on page 23

Visual voice controls

The arrangement of options on the screen will vary depending on the phone type and display size. You can access controls not shown on the current display by using the phone's < and > buttons to move between screen pages.

Button	Functions
Listen	<p>Accesses your mailbox. When pressed, the screen shows the number of New, Old and Saved messages. Select one of those options to start playback of messages in that category. Once message playback is selected, the available controls change:</p> <ul style="list-style-type: none"> • Previous: Play the previous message. • Next: Play the next message. • Rewind: Rewind approximately 5 seconds. • FFwd: Step forwards approximately 5 seconds. • Delete: Delete the current message. • Save: Mark the messaged as a saved message. • Copy: Copy the message to another mailbox. When pressed, the phone displays: <ul style="list-style-type: none"> - Pre-Rec: Record a message to attach to the start of the copied message. - Targets: Enter the destination for the message copy. - Done: Copy the message using the targets entered. • Pause: Pause the current message. Press the button again to unpause.
Main(0)	<p>Hunt group names may be displayed you have been configured for hunt group mailbox access. The number shows the number of new messages in the mailbox. Press the button to access the mailbox in the same way as the Listen option above.</p>
Message	<p>Record and send a voicemail message to another mailbox or mailboxes.</p>
Greeting	<p>Change the main greeting used for callers to your mailbox. If you have not recorded a greeting, the system's uses its default mailbox greeting.</p> <ul style="list-style-type: none"> • Record: Record a new greeting. • Listen: Listen to the current greeting or the new greeting just recorded. • Submit: Submit the new greeting just recorded. • Delete: Delete the current greeting. The mailbox reverts to using the default system greeting.
Email	<p>This system shows this option if you have a configured email address for voicemail email usage in the telephone system configuration. This control allows you to see and change the current voicemail email option used for new messages received by your mailbox. Use Change to change the mode displayed. Press Done to save the change. The modes are:</p> <ul style="list-style-type: none"> • Email Mode Off: Voicemail email is not used. • Email Mode Copy: Copy new voicemail messages to the email address, leaving the original message in the mailbox. • Email Mode Fwd: Forward new voicemail messages to the email address, deleting the original message from the mailbox. • Email Mode Alert: Send an alert email message to the email address, leaving the message in the mailbox.

Table continues...

Button	Functions
Password	Change the mailbox password. To do this requires entry of the existing password.
Voicemail	Switch voicemail usage on or off. When off, the voicemail system does not answer unanswered calls.

Related links

[Visual voice introduction](#) on page 23

Chapter 8: Additional Help and Documentation

The following pages provide sources for additional help.

Related links

[Forgotten Password](#) on page 26

[Getting Help](#) on page 26

[Additional Documentation](#) on page 27

Forgotten Password

Some IP Office features require you to enter information such as your username, password, login code (security PIN), voicemail code (mailbox password).

Avaya cannot or reset the values for your passwords and codes. However, your system administrator can reset the values if necessary, either doing it themselves or through a request to your Avaya business partner.

Your system administrator also sets the rules your IP Office system uses for allowable passwords and codes. The same rules are applied to all users.

Related links

[Additional Help and Documentation](#) on page 26

Getting Help

Avaya sells IP Office through accredited business partners. Those business partners provide direct support to their customers and escalate issues to Avaya if necessary.

If you require further support, you should first contact your own system administrator. They are able to access the full configuration of the IP Office system, either themselves or through a request to your system's Avaya business partner.

Whilst your system administrator/reseller cannot see your existing passwords, they can reset them in order to allow you to login again and then change the value.

Related links

[Additional Help and Documentation](#) on page 26

Additional Documentation

The [Avaya Documentation Center](#) website contains user guides and manuals for Avaya products. The links below cover user guides that you may find useful.

Phone User Guides

- [IP Office J100 Series Phone User Guide](#) | [IP Office J100 Series Quick Reference](#)
- [IP Office 1408/1416 Phone User Guide](#) | [IP Office 1408/1416 Telephone Quick Reference Guide](#)
- [IP Office 1608/1616 Phone User Guide](#) | [IP Office 1608/1616 IP Telephone Quick Reference Guide](#)
- [IP Office 9500 Series Phone User Guide](#) | [IP Office 9500 Series Quick Reference](#)
- [IP Office 9600 Series Phone User Guide](#) | [IP Office 9600 Series Quick Reference](#)
- [IP Office Analog Phone User Guide](#)

Application Guides

- [Using Avaya Workplace Client for IP Office](#)
- [Using the IP Office User Portal](#)
- *Using one-X Portal for IP Office*
- [Using IP Office SoftConsole](#)

Voicemail Mailbox User Guides

- [Using a Voicemail Pro IP Office Mode Mailbox](#)
- [Using a Voicemail Pro Intuity Mode Mailbox](#)
- [Using IP Office Embedded Voicemail Intuity Mode](#)
- [Using IP Office Embedded Voicemail IP Office Mode](#)

Related links

[Additional Help and Documentation](#) on page 26

Index

A

Administrator [26](#)
answering outcalling [22](#)

B

Business Partners [26](#)

C

call sender [11](#)
caller option [9](#)
caller overview [9](#)
calling sender [11](#)
cancel message [22](#)
cancel notification [22](#)
change setting overview [12](#)
changing password [12](#)
Changing settings [12](#)
configuring initial outcalling [19](#)

D

default mailbox [7](#)
Documentation [27](#)

E

email notification [17](#), [18](#)
embedded overview [6](#)
embedded voicemail [6](#)
Embedded Voicemail [6](#)

F

forgotten password [26](#)
forward message [11](#)
full mailbox [9](#)

G

greeting listening [14](#)

H

Help [26](#)

I

initial outcalling [19](#)

Intuity mode [6](#)
IP Office mode [6](#)

L

listen to greeting [14](#)
listen to messages [10](#)
listening to message [10](#)
listening to messages [10](#)
logging in normally [7](#)
login code [26](#)

M

mailbox controls [7](#)
mailbox introduction [9](#)
Mailbox mode [6](#)
Manuals [27](#)
message forwarding [11](#)
message saving [11](#)

N

name record [14](#)
normal login [7](#)

O

outcalling [19](#)
outcalling calls [22](#)
outcalling destination [20](#)
outcalling off [22](#)
outcalling on [21](#)
outcalling timeout [21](#)

P

password [26](#)
password changing [12](#)

R

record greeting [13](#)
recording name [14](#)
recording your greeting [13](#)
Reseller [26](#)

S

Save a message [11](#)
security PIN [26](#)

setting outcalling destination	20
setting outcalling timeout	21
switching email notification	17
switching off email	18
system administration	12
System Administrator	26

T

transfer option	14
transfer overview	14
trusted source	7
trusted source introduction	7
trusted sources	12
turning off outcalling	22
turning outcalling on	21

U

User guides	6
User Guides	27

V

visual voice	23
voice button	23
voicemail code	26
voicemail email	17
voicemail notification	16
Voicemail Pro	6
voicemail transfer	23